




No	Control Elements	No	Control Elements	No	Adjustments UP
A	Solenoid 'Up Stop'	V	Check Valve	1	By Pass
D	Solenoid 'Down Stop'	Y	Down Level Valve	5	Up Soft Stop
U	Bypass Valve	F	Main Filter	No	Adjustments DOWN
H	Manuel Lowering	S	Relief Valve	6	Down Acceleration
M1	Test Port			9	Down Levelling Speed

#	Description / Açıklama	Marka / Brand	Kod / Code	Ad/Q
10	Oil Tank	-	-	1
11	Filter	-	-	1
12	Pump	-	-	1
13	Motor	-	-	1
14	Pressure Switch	-	-	1
15	Hose Burst Valve	-	-	2
16	Cylinder	-	-	2

#	Description / Açıklama	Marka / Brand	Kod / Code	Ad/Q
21	Filter	-	-	1
22	Pump	-	-	1
23	Motor	-	-	1
24	Relief Valve	-	-	1
25	Check Valve	-	-	1
26	NG6 Valve (OC)	-	-	1
27	Lock Cylinder	-	-	4



KOD HS-HP 1122		Seri No / Serial No	HİDROLİK ŞEMA HYDRAULIC SCHEMA		Model	ÖNDER LİFT
					ESP	
TARİH	REVİZYON				DHYA	
28.08.2025	1					