



No	Control Elements	No	Control Elements	No	Adjustments UP
A	Solenoid 'Up Stop'	V	Check Valve	1	By Pass
D	Solenoid 'Down Stop'	Y	Down Level Valve	5	Up Soft Stop
U	Bypass Valve	F	Main Filter	No	Adjustments DOWN
H	Manuel Lowering	S	Relief Valve	6	Down Acceleration
M1	Test Port			9	Down Levelling Speed

#	Description / Açıklama	Marka / Brand	Kod / Code	Ad/Q
10	Oil Tank	-	-	1
11	Filter	-	-	1
12	Pump	-	-	1
13	Motor	-	-	1
14	Pressure Switch	-	-	1
15	Hose Burst Valve	-	-	1
16	Cylinder	-	-	1



KOD		Seri No / Serial No	HİDROLİK ŞEMA HYDRAULIC SCHEMA	Model	ÖNDER LİFT
HS-HP 1111				ESP DHYA	
TARİH	REVİZYON				
28.08.2025	1				