



2. Your P-Brick will be available over Bluetooth. Click on the button below the Bluetooth icon to connect.



3. Your computer will connect to your P-Brick. You might have to confirm the connection and password '1234' on your P-brick at this stage.

If you can't see the P-Brick in the Hardware Page in the application, continue with the following steps.


1. Open the Start Menu and click on 'Devices and Printers'.



2. Click on 'Add a device'.




3. It'll take a moment for your P-Brick to show up in the list of available devices. Select it and press 'Next'.




4. The PC will try to connect to the P-Brick.

5. Confirm connection and password on the P-Brick.

6. On the PC, enter "1234" like below and click 'Next'.



7. When the pairing process is done, the following window will pop up.



8. Repeat Steps 1-3.

If you have any problems, [get in touch with us](#).



Was this information helpful?



Yes



No

Didn't find what you need? [Contact us!](#) →

☆ POPULAR ARTICLES

| | |
|--|---|
| Identifying LEGO® set and part numbers | > |
| Buying individual LEGO® parts | > |
| How to download building instructions online | > |
| Creating your own minifigure | > |
| Product feedback survey in building instructions | > |
| Checking your LEGO® VIP account balance | > |
| Replacing stickers | > |
| New sets with missing parts | > |
| Replace missing or damaged building instructions | > |
| Digital building instructions for older sets | > |



NEED SUPPORT? CONTACT US

Our dedicated LEGO experts are here to help