

# Plotting the proportionality of absorbances across readers

Each point corresponds to a single read's absorbance values on the original and new plate readers. Solid diagonal line indicates direct proportionality.

