

S.No	FIELD	DATA TYPE	DESCRIPTION
1	N_LAT DATA	double	Latitude returned by NETWORK_PROVIDER
2	N_LONG DATA	double	Longitude returned by NETWORK_PROVIDER
3	F_LAT DATA	double	Latitude returned by FUSED API
4	F_LONG DATA	double	Longitude returned by FUSED API
5	LOCATION_PROVIDER DATA	int	Specifies what Location Manager class is using to fetch the location: 1(GPS), 2(NETWORK_PROVIDER)
6	TIMESTAMP DATA	long	Timestamp of log
7	NETWORK_TYPE DATA	int	Network type returned by getAllCellInfo() 0(GSM) 1(CDMA) 2(LTE) 3(WCDMA)
8	NETWORK_TYPE2 DATA	int	Network type returned by telephonyManager.getNetworkType() 0(unknown) 1(2G) 2(3G) 3(4G)
9	NETWORK_PARAM1 DATA	int	CID(GSM), BasestationID(CDMA), CI(LTE), CID(WCDMA)
10	NETWORK_PARAM2 DATA	int	LAC(GSM), NetworkID(CDMA), PCI(LTE), LAC(WCDMA)
11	NETWORK_PARAM3 DATA	int	MCC(GSM), SystemID(CDMA), MCC(LTE), MCC(WCDMA)
12	NETWORK_PARAM4 DATA	int	MNC(GSM), SystemID(CDMA), MNC(LTE), MNC(WCDMA)
13	DBM DATA	int	RSSI value returned by getDbm()
14	NETWORK_LEVEL DATA	int	Level value returned by getLevel()
15	DATA_STATE DATA	int	-1(Unknown) 0(Disconnected) 1(Connecting) 2(Connected) 3(Suspended)

S.No	FIELD	DATA TYPE	DESCRIPTION
16	DATA_ACTIVITY DATA	int	-1(Unknown) 0(None) 1(IN) 2(OUT) 3(IN_OUT) 4(DORMANT)
17	CALL_STATE DATA	int	0(IDLE) 1(Call in progress)