




## User LED




## Power LED




## 5V to 3V3




## USB Connector




## Power Input Selection




## USB to UART/Serial




## Serial Signal Handling




## Connectors/Headers




## ESP32 Module



## RESET BUTTON



## BOOT/USER BUTTON



[https://dl.espressif.com/dl/schematics/esp32\\_devkitc\\_v4-sch.pdf](https://dl.espressif.com/dl/schematics/esp32_devkitc_v4-sch.pdf)

[https://www.espressif.com/sites/default/files/documentation/esp32-wroom-32e\\_esp32-wroom-32u\\_datasheet\\_en.pdf](https://www.espressif.com/sites/default/files/documentation/esp32-wroom-32e_esp32-wroom-32u_datasheet_en.pdf)

