




Raspberry Pi 4 B

Metal Case Installation Guide



Any issue?

Please Contact US
Email: iUniker@yeah.net



Satisfied?

We are just very glad to know that you are Satisfied.

We appreciate that you post a review to let others benefits from your experience.

We appreciate your time and support and hope you will shop with us again.


Disappointed?

We are committed to provide practical, easy-to-use products as well as exceptional customer service.

The product is guaranteed for 12 months from the date of purchase. Please feel free to contact us with your ORDER NUMBER if you need a replacement or refund.

Email: iuniker@yeah.net

How to Install the Thermal Tape?





1

Pick up the bottom panel.




2

Put your Pi on it.



3



4

Remove the protective film from the back of thermal tape. Install them on the the Pi as picture show.



5

Install the top case.



6

Complete the installation.



7

Pick up 2 long screws and 2 short screws. Screw them by using screwdriver as picture show.



8

Install 4 Rubber Feet on the back of case.



9

Done!