

Product Manual: Smart Speaker X100

Resetting the Smart Speaker:

- To reset your Smart Speaker, press and hold the power button for 10 seconds until the LED indicator flashes.
- Once reset, the speaker will return to factory settings and all paired devices will be unpaired.

Pairing the Smart Speaker:

- To pair the Smart Speaker, press the Bluetooth button and hold for 3 seconds.
- The LED will flash blue, and the speaker will enter pairing mode.

FAQ:

Q: How do I reset my smart speaker?

A: Press and hold the power button for 10 seconds until the LED flashes.

Q: How do I pair my smart speaker with my phone?

A: Press the Bluetooth button for 3 seconds to enter pairing mode.