




## Power



## Cable Tester Clock




## Cable Tester Transmitter




Tester for RJ9 and RJ45 cables. Turns on LEDs on the transmit side in sequence and sends the signal through the connected cable. If the cable is connected properly, all the LEDs on the receiver should turn on in the same order.


## Cable Tester Receiver



## Cable Tester Mode Select



## Terminator Resistance Tester



Tester for CAN Terminators. LED turns on if the resistance between CANH and CANL (Pins 2 and 3) is 120R.

RJ Tester		
Size	Number	Revision
A3		
Date:	8/14/2024	Sheet of
File:	C:\Users\...MOASCT.SchDoc	Drawn By: llo