




电源





- 1.将ams1117和ams1117-3.3V (更改OK)
- 2.多开焊盘一个40K接口 (备用单口) (接口为 PMA, PA1)
- 3.多给几个40K输出, 接口可以并接输出输出为40K输出。
- 4.将AMS1117和ams1117-3.3V (更改OK)

接口



| REVISION RECORD | | | |
|-----------------|---------|----------|------|
| LTR | ECO NO. | APPROVED | DATE |
| | | | |
| | | | |
| | | | |



| | | | | | | |
|------------------|--------|----------|-------|-------|-------------|----------|
| DRAWN: | DATED: | COMPANY: | | Title | | |
| CHECKED: | DATED: | TITLE: | | | | |
| QUALITY CONTROL: | DATED: | CODE: | SIZE: | | DRAWING NO. | REV: |
| RELEASED: | DATED: | SCALE: | | | Sheet of | Revision |

2018/11/22
C:\Users\Sheet 1 SchDxe
Drawn By: