



NOTES

PURPLE PINS ARE RESERVED FOR ADA-FRUIT MUSIC-MAKER

THE 3-POS SWITCH IS NOT SHOWN.

CAN BE CONNECTED TO D9, D10 OR ANALOG PINS,

ON/OFF SWITCH NOT SHOWN