



Arm Joints left

mode indicator

USB

safety override

run factor
dead man

joint up
joint left
joint down
joint right

joint 7/gripper
joint 5/6
joint 3/4
joint 1/2

next mode

gripper joints

init/recover
pairing











