



REG1 5V




T5




SS3



2




SS2




1




SS1




T3



T1



0



P1  
Motor Driver  
Power  
2.5x5.5  
Center +  
+12-30VDC



T6



T4



T2

REF GND REFR GND

2

REF GND REFR GND

1

REF GND REFR GND

0

<https://github.com/janelia-modular-devices>

Disconnect Motor Driver Power  
Before Unplugging Motor Connectors

