






The release of the latest version of **NITRO** has some subtle differences of which we have detailed below. Please familiarise yourself with these changes to eliminate any confusion when installing **NITRO**

1. Differences to the Installation Process

Older Nitro (Version 4.7.5.3)	Latest Nitro (Version 5.3.0)
<p>While Installing any older version of Nitro, at the additional task window there will be a two-tick box pop up that allows user to install EMS-Client and USB Driver, as shown below</p> 	<p>While Installing the latest version of Nitro, at the additional task window the <u>USB Driver Option is no longer available</u>. Please choose EMS-Client option only as shown below</p>  <p>NOTE: Please use the USB driver that has been provided separately.</p>


Older Nitro (Version 4.7.5.3)

While setting up the EFT -Client, the options for the PINPad modem/printer configuration setting is displayed first in the list



Latest Nitro (Version 5.3.0)


In the new version of Nitro, the PINPad modem/printer configuration setting is now displayed last in the list



2. Name Change in Services – PC EFTPOS rebranded as LINKLY


Older Nitro (Version 4.7.5.3)

When starting or stopping services the Client appears as **PC-EFTPOS Client**





Latest Nitro (Version 5.3.0)



When starting or stopping services the Client appears as **LINKLY CLIENT**



3. Changes to the Icon

Older Nitro (Version 4.7.5.3)	Latest Nitro (Version 5.3.0)
<p>On the task bar (right hand side of a PC based POS system) the EFT-Client icon is as follows:</p> 	<p>On the task bar (right hand side of a PC based POS system) the EFT-Client icon is as follows:</p> 


4. Changes to Client GUI

Older Nitro (Version 4.7.5.3)	Latest Nitro (Version 5.3.0)
<p>In the older Nitro, Client GUI known as 'PC-EFTPOS'</p> 	<p>In latest Nitro PC-EFTPOS Client GUI rebranded as 'Linkly Client GUI'</p> 

5. Changes to the **CONTROL PANEL** window


Older Nitro (Version 4.7.5.3)

In old version the different functionalities appear under Control panel window are as below.



Latest Nitro (Version 5.3.0)

For latest Nitro, there are **two more functionalities (Surcharge & Tipping)** gets added as show below.



NOTE: Please keep in mind, our current S/W doesn't support Surcharge and Tipping with Nitro