



The Atelier
Touch to begin

System Startup

The system is getting ready.
It will automatically turn on in:

7

seconds

Cancel



Relax



PC



Collaborate





Relax



PC



Collaborate





Relax



PC



Collaborate







Relax

Signage content is currently displaying on the screens.


Preset 1:
Forest



Preset 2:
Seaside



Preset 3:
Mountains



Use the home button at the top of the screen to
change the system mode.




Relax

Signage content is currently displaying on the screens.


Preset 1:
Forest



Preset 2:
Seaside



Preset 3:
Mountains



Use the home button at the top of the screen to
change the system mode.




Relax

Signage content is currently displaying on the screens.


Preset 1:
Forest



Preset 2:
Seaside



Preset 3:
Mountains



Use the home button at the top of the screen to
change the system mode.



PC

PC content is currently displaying on the screens. Use the wireless keyboard, mouse, and interactive screens to control it.

Use the home button at the top of the screen to change the system mode.



Collaborate

The system is currently in independent collaboration mode.
Interact with the screens using their on-screen controls.

Use the home button at the top of the screen to change the
system mode.



Settings

Adjust power scheduling, startup mode, and microphone reinforcement levels.

Scheduling

Startup Time



7:00



Shutdown Time



19:00



Power Scheduled Days

Monday

Friday

Tuesday

Saturday

Wednesday

Sunday

Thursday

Startup Mode

Relax

PC

Collaborate

Use the home button at the top of the screen to change the system mode.

System Shutdown

Are you sure you want to turn off the AV?
It will automatically turn off in:

7

seconds

Cancel



Multipurpose Space

Touch to begin

System Startup

The system is getting ready.
It will automatically turn on in:

7

seconds

Cancel



Teams &
Presentation



Signage



Television





Teams &
Presentation



Signage



Television





Teams &
Presentation



Signage



Television





Signage


Digital signage content is currently displaying on the screens.

Use the home button at the top of the screen to change the system mode.



Television

Television content is currently displaying on the screens.



Use the home button at the top of the screen to change the system mode.



Settings

Adjust power scheduling, startup mode, and microphone reinforcement levels.

Scheduling

Startup Time



7:00



Shutdown Time



19:00



Power Scheduled Days

Monday

Friday

Tuesday

Saturday

Wednesday

Sunday

Thursday

Startup Mode

Teams

Signage

Television

Mic Volume

Lapel

Handheld



Use the home button at the top of the screen to change the system mode.

System Shutdown

Are you sure you want to turn off the AV?
It will automatically turn off in:

7

seconds

Cancel

Development Notes

- Development based on J23NA023-AVSPEC ROOMS-REV_04
- Specification description of Multipurpose & Atelier is considered to have been superseded by section 4.1 of the above document
- Faders set to minimum will also be muted to prevent unusable 'quiet zones' in fader ranges
- Design artifacts such as green plus icons on buttons, partially filled gauges/sliders, selection borders, etc. are from the design software and will not appear in final product
- Signage content to be provided by others