



## Power Supply




LED1 and R11 are optional and can be omitted to extend battery life.

Input voltage can be 7 to 20 volts but is typically a 9 volt battery.

## SSB Tone Pulser



## CW Pulser



Maximum 60V, 200 mA  
Positive or negative.

TITLE: Tuning Aid		REV: 1.1
Date: 2018-06-02		Sheet: 1/1
EasyEDA V4.1.3	Drawn By: tranter	