



## Power Supply




LED1 and R11 are optional and can be omitted to extend battery life.

Input voltage can be 7 to 20 volts but is typically a 9 volt battery.

## SSB Tone Pulser



## CW Pulser



Maximum 60V, 200 mA  
Positive or negative.

TITLE:

Tuning Aid

REV: 1.1

Date: 2018-06-01

Sheet: 1/1

EasyEDA V4.1.3

Drawn By: tranter