



The 3V and GND from the Bluetooth Button is shared with the board.



1. 5V  
2. A0  
3. GND

4. BT\_Pin  
5. 3V  
6. GND

Title		
Size	Number	Revision
A		
Date:	12/19/2020	Sheet of
File:	C:\Users\...\Schematic.SchDoc	Drawn By:

