

M0RVJ Micro:bit CW Transceiver

COMMANDS (Shake to access menu '?' is displayed)

Speed

A = 15WPM
B = 18WPM
C = 21WPM
D = 24WPM
E = 27WPM
F = 30WPM

Tone

G = 500hz
H = 550hz
I = 600hz
J = 650hz
K = 700hz
L = 750hz
M = 800hz

Channel

N = 1
O = 2
P = 3
Q = 4
R = 5
S = 6

Tutor

T = M0RVJ suggests cwops.org

Power

U = Low Power / QRP
V = High Power / QRO

Reset

Z = defaults A H N U

International Morse Code	
<div>1. The length of a dot is one unit. 2. A dash is three units. 3. The space between parts of the same letter is one unit. 4. The space between letters is three units. 5. The space between words is seven units.</div>	
A	• —
B	— • • •
C	— • — •
D	— • •
E	•
F	• • — •
G	— — •
H	• • • •
I	• •
J	• — — —
K	— • —
L	• — • •
M	— —
N	— •
O	— — —
P	• — — •
Q	— — • —
R	• — •
S	• • •
T	—
U	• • —
V	• • • —
W	• — —
X	— • • —
Y	— • — —
Z	— — • •
1	• — — — —
2	• • — — —
3	• • • — —
4	• • • • —
5	• • • • •
6	— • • • •
7	— — • • •
8	— — — • •
9	— — — — •
0	— — — — —