




JP1: 2-3
JP2: 7-8 (check manual)
JP3: 1-2
JP4: 1-2
JP5: ?
JP6: 1-2, 3-4
JP7: 1-2, 3-4

Note:
On ET-3400 schem, RE and O2 are NC
On MEM/IO schem, NMI, IRQ, HALT, 5V are all hand-written as GND.



ETA-3400 Modern Remake
(c) 2020-Present Scott M Baker
<http://www.smbaker.com/>

