

Create Nest Product with Nest Developer Account

Overview:

In prior versions of NST Manager, the Token that was used for authenticating NST Manager to Nest was an automated process that took place from within the NST Manager SmartApp. This process has now changed and requires the end user (you) to generate their own token by creating a Developer Account on Nest (this is free) and creating a New Product that will allow you to insert the information from this Product into the NST Manager SmartApp.

Contents

Creating your Nest Developer Account	2
Creating a New Product	2
Filling out the Product Information (Part 1):	3
Selecting Permissions (Part 2):.....	4
Product ID / Product Secret:	6
Copy / Paste to NST Manager:	7
Troubleshooting Errors:	8
You are missing the Client ID and Secret:	8
Oops! We've encountered an error. Please try again:	9

Creating your Nest Developer Account

- Go to [Nest Developer Portal](#) and create a new account (*If you don't have one!*)

Creating a New Product

- Click on Create New Product.



- The following screen will be displayed:

nest Developers

Go to Docs

Product Details

* indicates required field.

Enter product name (cannot include "Nest" or "Works with Nest")*

How will the product name be displayed to the user? [LEARN MORE](#)

Description*

Describe what your product will let customers do, and how your product will interact with Nest devices.

Categories*

Select up to two categories

Users*

Select targeted number of users

Support URL*

Enter support URL

Default OAuth Redirect URI [LEARN MORE](#)

OAuth Redirect URI (Leave blank for PIN-based authorization)

Additional OAuth Redirect URIs

Add OAuth Redirect URI...

Permissions

If you change permissions after the product is created, then your users will be notified and required to reauthorize the product with the new permissions.

You can change permission descriptions at any time. Users are not required to reauthorize products when descriptions change.

See a list of data fields in permissions. [LEARN MORE](#)

Filling out the Product Information (Part 1):

1) Product Name:

- Enter any unique name for your product (This name will be displayed in the Nest Application under “Works With Nest” in Settings).
- If you see the “**Name already in use**”, keep typing and give the product name something unique. The red text will disappear when your name is unique.

2) Description*:

- Copy / Paste the following text:

NST Manager allows you to integrate your Nest products with the SmartThings platform. It can be used to trigger or respond to various device events by using standard SmartThings capabilities. This allows for a high level customization of automations.

3) Categories*:

- Select the following Categories (you select each one individually)
 - a) HVAC
 - b) Home Automation

4) Users*:

- Select Individual

5) Support URL*:

- Copy / Paste the following URL:

<https://community.smartthings.com/t/release-nest-manager-v5-0/83228>

6) Default OAuth Redirect URL:

- Copy / Paste the following URL:

<https://graph.api.smartthings.com/oauth/callback>

Note: Verify that you didn't accidentally copy / paste the URL with any leading or trailing spaces. Your authentication will fail otherwise.

7) Additional OAuth Redirect URIs (Not Required)

- Leave this field blank

Selecting Permissions (Part 2):

Note: There are 5 Permissions that must be selected and set to Read or Read/Write in order for the NST Manager to function appropriately with your Nest Products.

Permissions

If you change permissions after the product is created, then your users will be notified and required to reauthorize the product with the new permissions.

You can change permission descriptions at any time. Users are not required to reauthorize products when descriptions change.

See a list of data fields in permissions. [LEARN MORE >](#)

☐

Away

☐

Camera + images

☐

ETA write

☐

Postal code

☐

Smoke+CO Alarm

☐

Thermostat

☐

Camera

☐

ETA read

☐

Energy

☐

Product data

Required only if you're using the [resource_use API](#). The Product data permission requires that you first [verify your company](#).

☐

Structure

Select the following permissions with the appropriate capability and copy / paste the description text

Away

- read/write v2
- Description to copy / paste:

NST Manager use SmartThings (Presence, Mode, or Switches) to change your Nest's Home/Away status.

Camera + Images

- read/write v4
- Description to copy / paste:

NST Manager uses many combinations of SmartThings device events to turn your Nest Camera on/off.

Postal Code

- read v2
- Description to copy / paste:

NST Manager uses your postal code when we are unable to determine your SmartThings location info.

Smoke + CO Alarm

- read v5
- Description to copy / paste:

NST Manager can trigger delayed alerts in SmartThings Platform that can perform tasks based on the alarm type.

Thermostat

- read/write v6
- Description to copy / paste:

NST Manager can trigger actions in SmartThings when a temperature, humidity, HVAC mode events occurs.

- When completed, the 5 Permissions you selected should match the following:

☒ Away

☐ read v2

☒ read/write v2

NST Manager use SmartThings (Presence, Mode, or Switches) to change your Nest's Home/Away status.

Preview

☒ Camera + images

☐ read v4

☒ read/write v4

NST Manager uses many combinations of SmartThings device events to turn your Nest Camera on/off.

Preview

☒ Postal code

☒ read v2

NST Manager uses your postal code when we are unable to determine your SmartThings location info.

Preview

☒ Smoke+ CO Alarm

☒ read v5

NST Manager can trigger delayed alerts in SmartThings Platform that can perform tasks based on the alarm type.

Preview

☒ Thermostat

☐ read v6

☒ read/write v6

NST Manager can trigger actions in SmartThings when a temperature, humidity, HVAC mode events occurs.

Preview

After you have completed and verified all of the above, you can proceed by pressing the Create Product button:

CREATE PRODUCT

Product ID / Product Secret:

Upon successful creation of your product, you will automatically be taken to the Overview screen:

Overview

 Edit

Review and update your product's information. [Learn more >](#)

NST for SmartThings version 4

Description

NST Manager allows you to integrate your Nest products with the SmartThings platform. It can be used to trigger or respond to various device events by using standard SmartThings capabilities. This allows for a high level customization of automations.

Categories

- HVAC
- Home Automation

Users

1 / 50

Support URL

<https://community.smarthings.com/t/release-nest-manager-v5-0/83228>

Default OAuth Redirect URI

<https://graph.api.smarthings.com/oauth/callback>

OAuth

Product ID

b084f248-8655-40fd-9824-e9314e89006b


Product Secret

DN4D9cevbU6zgETEOcrRCcIS6

Authorization URL

https://home.nest.com/login/oauth2?client_id=b084f248-8655-40fd-9824-e9314e89006b&state=STATE

Copy / Paste to NST Manager:

- 1) The Product ID and Product Secret above will need to be copied / pasted into the NST Manager SmartApp via IDE.
- 2) Login to IDE for SmartThings (You should already know how to do this as you have added the NST Manager SmartApp using this method already).
- 3) After logging in to IDE, select SmartApps and then press on the  icon on the left side next to NST Manager
- 4) Scroll down and select Settings:

Settings

App Settings:

Name	Value
clientId	Setting value
clientSecret	Setting value
devOpt	Setting value

Icons

OAuth

Resources (optional)

Update

Cancel

Delete

- 5) You will copy and paste the following fields from your Nest Developer Overview Console into the settings above in NST Manager IDE:
- 6)
 - Product ID → clientId
 - Product Secret → clientSecret

Notes:

- When copying / pasting the above, verify that you do not have leading or trailing spaces in the fields above. Authentication will fail otherwise.
- Do not share this information with anyone as it is unique to you and your products)
-


- 7) Press the Update button

If you have not yet, installed NST Manager from the Market Place in the SmartThings Mobile Application, you may proceed with those steps now. For those of you that have already previously installed NST Manager, you can open the NST Manager from Automation / SmartApps and follow the instructions on resetting your existing token.

Troubleshooting Errors:

If you encounter any of the following errors, please follow the steps to verify and correct the issue:

You are missing the Client ID and Secret:




If you encounter this message while trying to authenticate from the NST Manager Smart App to Nest:

- You either didn't copy / paste the Product ID and Product Secret from Nest Developer into the Settings in NST Manager and those two fields are blank (**Most common**)
- You performed a copy / paste of either the Product ID or Product Secret with a leading or trailing space
- You performed a copy / paste into the incorrect fields (IE: Product ID into ClientSecret)

Verify using the Copy / Paste to NST Manager on Page 7 above

Oops! We've encountered an error. Please try again:



Oops! We've encountered an error. Please try again.



Works with Nest

If you encounter this message while trying to authenticate from the NST Manager Smart App to Nest and you didn't receive the "Missing Client ID and Secret" error message above:

- You either didn't copy / paste the "Default OAuth Redirect URL" from step 6 in Filling out the product information
- You manually typed the Default OAuth Redirect URL incorrectly
- You performed a copy / paste and have a leading or trailing space in the Default OAuth Redirect URL

The correct Default OAuth Redirect URL is (Please Copy / Paste this URL into your Nest Developer Product):

<https://graph.api.smarthings.com/oauth/callback>