

rusEFI.com

Sheet: /DC Driver 1/  
File: DC\_MOTOR\_0.1.kicad\_sch


**Title: UAEFI**

Size: A4 Date: 2025-04-30

KiCad E.D.A. 8.0.9

**Rev: E**

Id: 2/9



rusEFI.com

Sheet: /LS/  
File: LS4.kicad\_sch


**Title: UAEFI**

Size: A4 Date: 2025-04-30

KiCad E.D.A. 8.0.9

**Rev: E**

Id: 3/9



rusEFI.com

Sheet: /DC Driver 2/  
File: DC\_MOTOR\_0.1.kicad\_sch

**Title: UAEFI**


Size: A4 Date: 2025-04-30

KiCad E.D.A. 8.0.9


**Rev: E**

Id: 4/9

Id: 6/9



Remove R20-R22, R26-R28, and install Q7-Q12 for use with dumb coils



rusEFI.com

Sheet: /Ignition/  
File: IGN6.kicad\_sch


**Title: UAEFI**

Size: A4 Date: 2025-04-30

KiCad E.D.A. 8.0.9

**Rev: E**

Id: 9/9



NUP2105L is optional, used for protection

rusEFI.com

Sheet: /EGT/  
File: egt.kicad\_sch

**Title: UAEFI**


Size: A4 Date: 2025-04-30

KiCad E.D.A. 8.0.9

**Rev: E**

Id: 9/9





rusEFI.com

Sheet: /Injector/

File: INJ6.kicad\_sch

**Title: UAEFI**

Size: A4

Date: 2025-04-30

Rev: E

KiCad E.D.A. 8.0.9

Id: 10/9