

# 3D REPO

## Embedded Viewer Guide


Version 2.10

This user guide will help you set up the 3D Repo embedded viewer. Once you have downloaded the zip file, simply follow the step-by-step guide below to set up a simple viewer integration. For any further support, contact 3D Repo on [support@3drepo.com](mailto:support@3drepo.com).

## Setup Instructions

1. Launch the index.html file in a web browser
2. Enter your 3drepo.io credentials when prompted
3. Once the viewer has loaded, simply copy/paste your model ID into the box to load a model

**Please note:** Different model IDs can be copied from 3drepo.io URLs, as shown in the image below.



## API Documentation for UnityUtils Library

<https://3drepo.github.io/3drepo.io/frontend/classes/unityutil.html>

## 3D Repo API

<https://3drepo.github.io/3drepo.io/>