

Percussion Kit list

		Drum					
		ELKIt 1	ELKIt 2	Standard Kit 1	Standard Kit 2	Hit Kit	Room Kit
Lower Keyboard	C-1	C#-1	Scratch	Maracas High	Surdo Mute	Surdo Mute	Surdo Mute
	D-1	D#-1	Concert BD	Surdo Mute	Surdo Open	Surdo Open	Surdo Open
	E-1		Noise Percussion	Maracas Low	Hi Q	Hi Q	Hi Q
	F-1	F#-1	Bass Drum March	Surdo Muff	Whip Slap	Whip Slap	Whip Slap
	G-1	G#-1	Analog BD Short	Surdo Rim	Scratch H	Scratch H	Scratch H
	A-1	A#-1	Synth Tom 3	Cuica High	Scratch L	Scratch L	Scratch L
	B-1		Analog BD Long	Surdo Open	Finger Snap	Finger Snap	Finger Snap
	C0	C#0	Synth Tom 2	Cuica Middle	Click Noise	Click Noise	Click Noise
	D0	D#0	Synth Bass Drum	Tamborim Mute	Metronome Click	Metronome Click	Metronome Click
	E0		Synth Tom 1	Cuica Low	Metronome Bell	Metronome Bell	Metronome Bell
	F0	F#0	Bass Drum Attack	Tamborim Open	Seq Click L	Seq Click L	Seq Click L
	G0	G#0	Bass Drum Heavy	Pandeiro	Seq Click H	Seq Click H	Seq Click H
	A0	A#0	Tom 4	Bongo High	Brush Tap	Brush Tap	Brush Tap
	B0		Bass Drum Light	Conga Slide	Brush Swirl *	Brush Swirl *	Brush Swirl *
	C1	C#1	Tom 3	Bongo Low	Brush Slap	Brush Slap	Brush Slap
	D1	D#1	Orch Snare Drum	Conga Slap	Brush Tap Swirl *	Brush Tap Swirl *	Brush Tap Swirl *
	E1		Snare Drum Roll *	Conga Muff	Snare Roll *	Snare Roll *	Snare Roll *
	F1	F#1	Tom 2	Bongo Mute	Castanet	Castanet	Castanet
	G1	G#1	SD Brush Roll	Conga High	Snare Soft	Snare Soft 2	Snare Electro
	A1	A#1	Tom 1	Bongo Slap	Sticks	Sticks	Sticks
	B1		SD Brush Shot 2	Conga Low	Kick Soft	Kick Tight L	Kick Soft
	C2	C#2	Tom Brush Shot 4		Open Rim Shot	Open Rim Shot H	Snare Pitched
	D2	D#2	SD Brush Shot 1	Timbale 1 High	Kick Tight	Kick Tight	Kick Tight
	E2		SD Heavy	Timbale 1 Low	Kick	Kick Short	Kick Tight H
	F2	F#2	Tom Brush Shot 3		Side Stick	Side Stick Light	Stick Ambient
	G2	G#2	Snare Drum Light	Timbale 2 High	Snare	Snare Short	Snare Ambient
	A2	A#2	Tom Brush Shot 2		Hand Clap	Hand Clap	Hand Clap
	B2		SD Accent 2	Timbale 2 Low	Snare Tight	Snare Tight H	Snare Tight 2
	C3	C#3	SD Accent 1	Timbale 3 High	Floor Tom L	Floor Tom L	Hybrid Tom 1
	D3	D#3	Tom Brush Shot 1	Wood Block High	Hi-Hat Closed	Hi-Hat Closed	Hi-Hat Closed 2
	E3		SD Reverb 2	Timbale 3 Low	Floor Tom H	Floor Tom H	Hybrid Tom 2
F3	F#3	Snare Drum Rim 2	Wood Block Mid	Hi-Hat Pedal	Hi-Hat Pedal	Hi-Hat Pedal 2	
G3	G#3	SD Reverb 1	Timbale 4 High	Low Tom	Low Tom	Hybrid Tom 3	
A3	A#3	Snare Drum Rim 1	Wood Block Low	Hi-Hat Open	Hi-Hat Open	Hi-Hat Open 2	
B3		Synth Snare Drum	Timbale 4 Low	Mid Tom L	Mid Tom L	Hybrid Tom 4	
C4	C#4	Analog SD	Vibraslap	Mid Tom H	Mid Tom H	Hybrid Tom 5	
D4	D#4	Triangle Mute	Triangle Mute	Crash Cymbal 1	Crash Cymbal 1	Crash Cymbal 1	
E4		Tambourine	Tambourine	High Tom	High Tom	Hybrid Tom 6	
F4	F#4	Triangle Open	Triangle Open	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	
G4	G#4	Castanet	Castanet	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	
A4	A#4	Claves	Claves	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	
B4				Tambourine	Tambourine Light	Tambourine	
C5	C#5	Cabasa	Cabasa	Splash Cymbal	Splash Cymbal	Splash Cymbal	
D5	D#5			Cowbell	Cowbell	Cowbell	
E5		Finger Snap	Finger Snap	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	
F5	F#5			Vibraslap	Vibraslap	Vibraslap	
G5		Hand Claps	Hand Claps	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	
Upper Keyboard							

*: Indicates an instrument which requires the Gate Time setting.

		Drum					
		Rock Kit	Electro Kit	Analog Kit	Dance Kit	Jazz Kit	Brush Kit
Lower Keyboard	C-1	C#-1	Surdo Mute	Surdo Mute	Kick Dance 1	Surdo Mute	Surdo Mute
	D-1	D#-1	Surdo Open	Surdo Open	Kick Dance 2	Surdo Open	Surdo Open
	E-1		Hi Q	Hi Q	Hi Q	Hi Q	Hi Q
	F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	Whip Slap	Whip Slap
	G-1	G#-1	Scratch H	Scratch H	Scratch Dance 1 *	Scratch H	Scratch H
	A-1	A#-1	Scratch L	Scratch L	Scratch Dance 2 *	Scratch L	Scratch L
	B-1		Finger Snap	Finger Snap	Finger Snap	Finger Snap	Finger Snap
	C0	C#0	Click Noise	Click Noise	Click Noise	Click Noise	Click Noise
	D0	D#0	Metronome Click	Metronome Click	Dance Perc 1	Metronome Click	Metronome Click
	E0		Metronome Bell	Metronome Bell	Reverse Dance 1	Metronome Bell	Metronome Bell
	F0	F#0	Seq Click L	Seq Click L	Dance Perc 2	Seq Click L	Seq Click L
	G0	G#0	Seq Click H	Seq Click H	Hi Q Dance 1	Seq Click H	Seq Click H
	A0	A#0	Brush Tap	Brush Tap	Snare Analog 3	Brush Tap	Brush Tap
	B0		Brush Swirl *	Brush Swirl *	Vinyl Noise *	Brush Swirl *	Brush Swirl *
	C1	C#1	Brush Slap	Brush Slap	Snare Analog 4	Brush Slap	Brush Slap *
	D1	D#1	Brush Tap Swirl *	Reverse Cymbal *	Reverse Cymbal *	Brush Tap Swirl *	Brush Tap Swirl
	E1		Snare Roll *	Snare Roll *	Reverse Dance 2 *	Snare Roll *	Snare Roll *
	F1	F#1	Castanet	Hi Q 2	Hi Q 2	Castanet	Castanet
	G1	G#1	Snare Noisy	Snare Snap Elec	Snare Noisy 4	Snare Jazz H	Brush Slap 2
	A1	A#1	Sticks	Sticks	Snare Dance 1	Sticks	Sticks
	B1		Kick Soft	Kick 3	Kick Techno Q	Kick Soft	Kick Soft
	C2	C#2	Open Rim Shot	Open Rim Shot	Rim Gate	Open Rim Shot	Open Rim Shot
	D2	D#2	Kick 2	Kick Gate	Kick Techno L	Kick Tight	Kick Tight
	E2		Kick Gate	Kick Gate Heavy	Kick Techno	Kick Jazz	Kick Jazz
	F2	F#2	Side Stick	Side Stick	Side Stick Anlg	Side Stick Light	Side Stick Light
	G2	G#2	Snare Rock	Snare Analog 2	Snare Analog	Snare Clap L	Brush Slap 3
	A2	A#2	Hand Clap	Hand Clap	Dance Clap	Hand Clap	Hand Clap
	B2		Snare Rock Tight	Snare Noisy 3	Snare Dry	Snare Jazz M	Brush Tap 2
	C3	C#3	Tom Rock 1	Tom Electro 1	Tom Analog 1	Floor Tom L	Tom Brush 1
	D3	D#3	Hi-Hat Closed	Hi-Hat Closed	Hat Close Analog	Hi-Hat Closed 3	Hi-Hat Closed
	E3		Tom Rock 2	Tom Electro 2	Tom Analog 2	Tom Dance 1	Floor Tom H
	F3	F#3	Hi-Hat Pedal	Hi-Hat Pedal	Hat Close Anlg 2	Hat Close Anlg 3	Hi-Hat Pedal
	G3	G#3	Tom Rock 3	Tom Electro 3	Tom Analog 3	Tom Dance 2	Tom Brush 2
	A3	A#3	Hi-Hat Open	Hi-Hat Open	Hat Open Analog	Hi-Hat Open 3	Hi-Hat Open
	B3		Tom Rock 4	Tom Electro 4	Tom Analog 4	Tom Dance 3	Tom Brush 3
	C4	C#4	Tom Rock 5	Tom Electro 5	Tom Analog 5	Tom Dance 4	Tom Brush 4
	D4	D#4	Crash Cymbal 1	Crash Cymbal 1	Crash Analog	Crash Cymbal 1	Crash Cymbal 1
	E4		Tom Rock 6	Tom Electro 6	Tom Analog 6	High Tom	Tom Brush 5
	F4	F#4	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1
	G4	G#4	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal
	A4	A#4	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup
	B4		Tambourine	Tambourine	Tambourine Anlg	Tambourine	Tambourine
Upper Keyboard	C5	C#5	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal
	D5	D#5	Cowbell	Cowbell	Cowbell Dance	Cowbell	Cowbell
	E5		Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2
	F5	F#5	Vibraslap	Vibraslap	Vibraslap Analog	Vibraslap	Vibraslap
	G5		Ride Cymbal 2	Ride Cymbal 2	Ride Analog	Ride Cymbal 2	Ride Cymbal 2
	A5		Bongo H	Bongo H	Bongo Analog H	Bongo H	Bongo H
	B5		Bongo L	Bongo L	Bongo Analog L	Bongo L	Bongo L
	C6		Conga H Mute	Conga H Mute	Conga Analog H	Conga H Mute	Conga H Mute
	D6		Conga H Open	Conga H Open	Conga Analog M	Conga H Open	Conga H Open
	E6		Conga L	Conga L	Conga Analog L	Conga L	Conga L
	F6		Timbale H	Timbale H	Timbale H	Timbale H	Timbale H
	G6		Timbale L	Timbale L	Timbale L	Timbale L	Timbale L
	A6		Agogo H	Agogo H	Agogo H	Agogo H	Agogo H
	B6		Agogo L	Agogo L	Agogo L	Agogo L	Agogo L
	C7		Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
	D7		Maracas	Maracas	Maracas 2	Maracas	Maracas
	E7		Samba Whistle H *	Samba Whistle H *	Samba Whistle H *	Samba Whistle H *	Samba Whistle H *
	F7		Samba Whistle L *	Samba Whistle L *	Samba Whistle L *	Samba Whistle L *	Samba Whistle L *
	G7		Guiro Short	Guiro Short	Guiro Short	Guiro Short	Guiro Short
	A7		Guiro Long *	Guiro Long *	Guiro Long *	Guiro Long *	Guiro Long *
	B7		Claves	Claves	Claves 2	Claves	Claves
	C8		Wood Block H	Wood Block H	Wood Block H	Wood Block H	Wood Block H
	D8		Wood Block L	Wood Block L	Wood Block L	Wood Block L	Wood Block L
	E8		Cuica Mute	Scratch H 2	Scratch H 2	Cuica Mute	Cuica Mute
	F8		Cuica Open	Scratch L 2	Dance Breath 1	Cuica Open	Cuica Open
	G8		Triangle Mute	Triangle Mute	Dance Breath 2 *	Triangle Mute	Triangle Mute
	A8		Triangle Open	Triangle Open	Triangle Open	Triangle Open	Triangle Open
	B8		Shaker	Shaker	Shaker	Shaker	Shaker
	C9		Jingle Bells	Jingle Bells	Jingle Bells	Jingle Bells	Jingle Bells
	D9		Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	E9						
	F9						
	G9						

*: Indicates an instrument which requires the Gate Time setting.

Upper Keyboard

166 ELS-02/ELS-02C Owner's Manual

10

Lower Keyboard

Upper Keyboard

ELS-02/ELS-02C Owner's Manual

		Drum					
		Live!Rock Kit	Live!Real Drums	Live!RealBrushes	Analog T8 Kit	Analog T9 Kit	House Kit
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	Surdo Mute	Surdo Mute	W Kick *
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	Surdo Open	Surdo Open	Disco Fx *
E-1		Hi Q	Hi Q	Hi Q	Hi Q	Hi Q	WhiteNoiseDown 1 *
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	Whip Slap	Whip Slap	PinkNoise Down 1 *
G-1	G#-1	Scratch H	Scratch H	Scratch H	Scratch H	Scratch H	WhiteNoiseDown 2 *
A-1	A#-1	Scratch L	Scratch L	Scratch L	Scratch L	Scratch L	PinkNoise Down 2 *
B-1		Finger Snap	Finger Snap	Finger Snap	Snare Hammer	Snare Drum&Bass1	White Noise Up 2 *
C0	C#0	Click Noise	Click Noise	Click Noise	Kick Zap Hard	Kick Break 2	White Noise Up 1 *
D0	D#0	Metronome Click	Metronome Click	Metronome Click	Snare Garg L	Snare Distortion	Pink Noise Up *
E0		Metronome Bell	Metronome Bell	Metronome Bell	Kick Tek Power	Kick Tek Power	WhiteNoiseUp Rel *
F0	F#0	Seq Click L	Seq Click L	Vintage Tip	Kick Slimy	KickDistortionRM	PinkNoise Up Rel *
G0	G#0	Seq Click H	Seq Click H	Vintage Swirl 1 *	Kick T8 4	Kick T9 2	Kick T9 4
A0	A#0	Brush Tap	Brush Tap	Vintage Slap 1	Snare Analog CR	Snare Analog CR	Snare T8 Rim
B0		Brush Swirl *	Brush Tap Swirl *	Vintage Swirl 2 *	Snare T8 7	Snare T9 5	Snare T8 5
C1	C#1	Brush Slap	Brush Slap	Vintage Slap 2	SnareClap Analog	Clap Analog Sm	Hand Clap
D1	D#1	Brush Tap Swirl *	Brush Tap Swirl *	Vintage TapSwirl *	Snare T8 6	Snare T9 Gate 1	Snare Garg L
E1		Snare Roll Rock *	Snare Roll Rock *	VintageSlapSwirl *	Tom T8 5	Snare Rock Roll *	Snare Roll *
F1	F#1	Castanet	Castanet	Vintage Swirl 3 *	Snare T8 5	Snare T9 3	Snare T9 3
G1	G#1	Snare Soft Rock	Snare Tight	Vintage Slap 3	Kick T8 3	Snare T9 4	Snare T8 1
A1	A#1	Sticks	Sticks	Sticks	Snare T8 4	Snare T9 Gate 2	Snare T9 5
B1		Kick Soft Rock	Kick Genuine	Kick Soft L	Kick T8 2	Kick T9 4	Kick T9 1
C2	C#2	Rim Rock	Rim Real	Open Rim Shot RB	Snare T8 3	Snare T9 6	Snare T9 Gate
D2	D#2	Kick Rock Heavy	Kick Real 1	Kick Soft H	T8 Kick Bass	Kick T9 1	Kick T9 2
E2		Kick Rock	Kick Real 2	KickJazzAmbience	Kick T8 1	Kick T9 3	Kick T9 5
F2	F#2	Stick Rock	Stick Real	Stick Brush	Snare T8 Rim	Snare T9 Rim	Snare T9 Rim
G2	G#2	Snare Rock	Snare Real 1	Vintage Slap 4	Snare T8 2	Snare T9 1	Snare T9 1
A2	A#2	Hand Clap Power	Clap Power	Clap Power	Clap T9	Clap T9	Clap T9
B2		Snare Dry Rock	Snare Real 2	Vintage Slap 5	Snare T8 1	Snare T9 2	Snare T9 2
C3	C#3	Tom Rock 1	Tom Real 1	TomRealBrushes 1	Tom T8 1	Tom T9 1	Tom T9 1
D3	D#3	Hi-HatClosedRock	Hi-HatClosedReal	Hi-Hat Closed RB	Hi-Hat Closed T8	Hi-Hat Closed T9	Hi-Hat Closed T8
E3		Tom Rock 2	Tom Real 2	TomRealBrushes 2	Tom T8 2	Tom T9 2	Tom T9 2
F3	F#3	Hi-HatPedal Rock	Hi-Hat PedalReal	Hi-Hat Pedal RB	Hi-Hat Pedal T8	Hi-Hat Pedal T9	Hi-Hat Pedal T9
G3	G#3	Tom Rock 3	Tom Real 3	TomRealBrushes 3	Tom T8 3	Tom T9 3	Tom T9 3
A3	A#3	Hi-Hat Open Rock	Hi-Hat Open Real	Hi-Hat Open RB	Hi-Hat Open T8	Hi-Hat Open T9	Hi-Hat Open T9
B3		Tom Rock 4	Tom Real 4	TomRealBrushes 4	Tom T8 4	Tom T9 4	Tom T9 4
C4	C#4	Tom Rock 5	Tom Real 5	TomRealBrushes 5	Tom T8 6	Tom T9 5	Tom T9 5
D4	D#4	CrashCymbalAco 1	CrashCymbalReal1	CrashCymbal RB 1	Crash Cymbal T8	Crash Cymbal T9	Crash Cymbal T9
E4		Tom Rock 6	Tom Real 6	TomRealBrushes 6	Tom T8 7	Tom T9 6	Tom T9 6
F4	F#4	RideCymbal Aco 1	RideCymbalReal 1	Ride Cymbal RB	Ride Cymbal T9	Ride Cymbal T9	Ride Cymbal T9
G4	G#4	China Cymbal Aco	ChinaCymbal Real	ChinaCymbal RB	China Cymbal 2	China Cymbal 2	Crash Cymbal 4
A4	A#4	RideCymbalCupAco	RideCym Cup Real	Ride Cup RB 1	RideCymbal Cup 2	RideCymbal Cup 2	RideCymbal Cup 2
B4		Tambourine	Tambourine	Tambourine	Tambourine RX5	Tambourine RX5	Tambourine Hit
C5	C#5	SplashCymbal Aco	SplashCymbalReal	Splash Cymbal RB	Splash Cymbal	Splash Cymbal 2	Splash Cymbal 2
D5	D#5	Cowbell	Cowbell	Cowbell	Cowbell T8	Cowbell 1	Cowbell 1
E5		CrashCymbalAco 2	CrashCymbalReal2	CrashCymbal RB 2	Crash Cymbal 4	Crash Cymbal 4	Crash Cymbal 1
F5	F#5	Vibraslap	Vibraslap	Vibraslap	Cowbell T8	Cowbell T8	Cowbell T8
G5	G#5	RideCymbal Aco 2	RideCymbalReal 2	Ride Cup RB 2	Ride Cymbal 3	Ride Cymbal 3	Ride Cymbal 3
A5	A#5	Bongo H	Bongo H	Bongo H	Conga T8 5	Conga T8 5	Bongo H Open 1 F
B5		Bongo L	Bongo L	Bongo L	Conga T8 4	Conga T8 4	Bongo L Open 3 F
C6	C#6	Conga H Mute	Conga H Mute	Conga H Mute	Conga T8 3	Conga Tip	Conga H Tip
D6	D#6	Conga H Open	Conga H Open	Conga H Open	Conga T8 2	Conga Open Slap	Conga H SlapOpen
E6		Conga L	Conga L	Conga L	Conga T8 1	Conga Open	Conga H Open 2
F6	F#6	Timbale H	Timbale H	Timbale H	Timbale H	Timbale H	Timbale H
G6	G#6	Timbale L	Timbale L	Timbale L	Timbale L	Timbale L	Timbale L
A6	A#6	Agogo H	Agogo H	Agogo H	Glass H	Analog Click	Agogo H
B6		Agogo L	Agogo L	Agogo L	Glass L	Conga T8 1	Agogo L
C7	C#7	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
D7	D#7	Maracas	Maracas	Maracas	Maracas T8	Maracas Slur 2	Maracas Slur 2
E7		Samba Whistle H *	Samba Whistle H *	Samba Whistle H *	Fx Gun 2 *	Fx Gun 2 *	Vox Drum L
F7	F#7	Samba Whistle L *	Samba Whistle L *	Samba Whistle L *	Fx Gun 1 *	Fx Gun 1 *	Vox Drum H
G7	G#7	Guiro Short	Guiro Short	Guiro Short	Analog Shaker H *	Scratch H 3 *	Guiro Short
A7	A#7	Guiro Long *	Guiro Long *	Guiro Long *	Analog Shaker L *	Scratch Down *	Guiro Long *
B7		Claves	Claves	Claves	Claves T8	Hi Q 3	Claves
C8	C#8	Wood Block H	Wood Block H	Wood Block H	Hi Q 1	Wood Block H	Wood Block H
D8	D#8	Wood Block L	Wood Block L	Wood Block L	Hi Q 2	Hi Q 2	Wood Block L
E8		Cuica Mute	Cuica Mute	Cuica Mute	Scratch H 2	Scratch H 2	Cuica H
F8	F#8	Cuica Open	Cuica Open	Cuica Open	Scratch L 2	Cuica L	Cuica L
G8	G#8	Triangle Mute	Triangle Mute	Triangle Mute	Triangle Mute	Triangle Mute	Triangle Mute
A8	A#8	Triangle Open	Triangle Open	Triangle Open	Triangle Open	Triangle Open	Triangle Open
B8		Shaker	Shaker	Shaker	Analog Shaker	Analog Shaker	Analog Shaker
C9	C#9	Jingle Bells	Jingle Bells	Jingle Bells	Sleigh Bells	Sleigh Bells	Sleigh Bells
D9	D#9	Wind Chime	Wind Chime	Wind Chime	Wind Chime	Wind Chime	Wind Chime
E9					Snare Hip 1	Snare Piccolo	Snare Break Roll
F9	F#9				Snare Hip 2	Snare T8 7	Noise Burst
G9	G#9				Snare Hip Gate	SnareRckRollDist	Vox Bell
A9	A#9				Snare Break 1	Snare Brush Mute	Snare R&B 1
B9					Kick Blip	Kick Blip Hard	Vox Alk
C10	C#10				Snare Fx 1	Snare Jungle 1	Udu High
D10	D#10				Kick Fx Hammer	Kick Sustain	Filter Kick

Lower Keyboard

Upper Keyboard

		Drum			SFX		
		HipHop Kit	Drum Machine	Break Kit	SFX Kit 1	SFX Kit 2	Live! SFX Kit 1
Lower Keyboard	C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute		
	D-1	D#-1	Surdo Open	Surdo Open	Surdo Open		
	E-1		Hi Q	Hi Q	Hi Q		
	F-1	F#-1	Whip Slap	Whip Slap	Whip Slap		
	G-1	G#-1	Scratch H	Scratch H	Scratch H		
	A-1	A#-1	Scratch L	Scratch L	Scratch L		
	B-1		Hi-HatClosedT8 2	Snare Drum&Bass1	Finger Snap		
	C0	C#0	Tom T8 3	Kick Break 2	Snare Break 8		
	D0	D#0	Hi-Hat Open T8 2	Snare Distortion	Snare Break 9		
	E0		Tom T8 6	Kick Tek Power	Hi-HatClosedBrk1 *		
	F0	F#0	Crash T8	KickDistortionRM	Hi-HatClosedBrk2 *		
	G0	G#0	Triangle Mute	BassDrumHardLong	Kick Break Deep		
	A0	A#0	Triangle Open	BassDrumTekPower	Snare Hip		
	B0		Wind Chime	Bass Drum Dist 5	Snare Lo-Fi		
	C1	C#1	TambourineLight2	Bass Drum Dist 3	Snare Clappy		
	D1	D#1	TambourineLight1	Bass Drum Dist 1 *	Snare LdwH Mono		
	E1		Kick HipHop 9	BD Drum & Bass 1	Snare Rock Roll *		
	F1	F#1	Hi-HatClosed Tek	Bass Drum Blip	Snare Gate 1		
	G1	G#1	Kick Gate	BassDrumAnalogSm	Snare Mid		
	A1	A#1	Hi-HatOpen Lo-Fi	Kick T8 2	Snare Break Rim		
	B1		KickGranCasaOpen	Kick T8 3	Kick Break Heavy		
	C2	C#2	Hi-HatReversed&B	Kick T9 HD 3	Snare Hip Rim 4		
	D2	D#2	Kick HipHop 1	Kick T9 2	Kick Break 2		
	E2		Kick Analog CR	Kick T9 4	Kick Break 1	Cutting Noise 1 *	Cutting Noise 1 *
	F2	F#2	SnareAnalogSmRim	Snare T9 Rim	Snare Hip Rim 1	Cutting Noise 2 *	Cutting Noise 2 *
	G2	G#2	Snare HipHop 1	Snare T9 1	Snare Break 3	Door Squeak *	Door Slam *
	A2	A#2	Snare Clappy	Clap T9	Snare Break 1	String Slap *	Scratch Cut *
	B2		Snare HipHop 2	Snare T9 4	Snare Break 2	String Slap *	Scratch Split *
	C3	C#3	Floor Tom L	Tom T9 1	Tom Break 1	Wind Chime *	Telephone Ring *
	D3	D#3	Hi-HatClosed Hip	Hi-Hat Closed T9	HHClosedRockSoft		
	E3		Low Tom	Tom T9 2	Tom Break 2		
	F3	F#3	Hi-Hat Pedal Hip	Hi-Hat Pedal T9	Hi-Hat PedalRock		
	G3	G#3	Mid Tom L	Tom T9 3	Tom Break 3		
	A3	A#3	Hi-Hat Open Hip	Hi-Hat Open T9	HH HalfOpen Rock		
	B3		High Tom	Tom T9 4	Tom Break 4		
	C4	C#4	Ride Cymbal 3	Tom T9 5	Tom Break 5		
	D4	D#4	Crash Cymbal 3	Crash Cymbal T9	Crash Cymbal 1		
Upper Keyboard	E4		Shaker 2	Conga T8 1	Tom Break 6		
	F4	F#4	ScratchBDForward	Ride Cymbal T9	Ride Cymbal 3		
	G4	G#4	ScratchBDRReverse	Conga T8 2	China Cymbal 2	Flute Key Click *	CarEngrn Ignition *
	A4	A#4	Kick HipHop 2	Analog Click	RideCymbal Cup 2	Car Tires Squeal *	Flute Key Click *
	B4		SnareHipHopRim 2	Claves T8 1	Tambourine 1 Hit	Car Passing *	
	C5	C#5	HipHop Clap 2	Maracas T8	Splash Cymbal 2	Car Crash *	
	D5	D#5	HipHop Snap 1	TambourineAna CR	Cowbell 1	Siren *	
	E5		Snare HipHop 3	Analog Shaker	Crash Cymbal 2	Train *	
	F5	F#5	Electric Clap 2	Cowbell T8	Cowbell RX11	Jet Plane *	
	G5	G#5	Kick Hip Deep	CowbellAnalog CR	Ride Cymbal 2	Starship *	
	A5	A#5	Kick HipHop 3	Snare T8 1	Bongo H	Burst *	
	B5		SnareHipHopRim 3	Snare T8 2	Bongo L	Roller Coaster *	
	C6	C#6	Snare HipHop 5	Snare T8 3	Conga H Tip	Submarine *	
	D6	D#6	Electric Clap 1	Snare Analog CR	Conga H OpenSlap		
	E6		Handbell H	Snare Jungle 1	Conga H Open		
	F6	F#6	Kick HipHop 4	Snare Drum&Bass2	Bongo 2 H		
	G6	G#6	HipHop Clap 3	Snare Hip 1	Bongo 2 L		
	A6	A#6	HipHop Snap 2	Snare R&B 1	Conga Open		
	B6		SnareHipHopRim 5	Snare R&B 2	Agogo L	Shower *	Laugh *
	C7	C#7	HipHop flex 1	Snare Hip 1	Cabasa	Thunder *	Shower 2 *
	D7	D#7	HipHop flex 2	Snare Wood	Maracas Slur	Wind *	Thunder 2 *
	E7		Shaker 2	Snare Timbre	Timbale H	Punch *	Wind 2 *
	F7	F#7	Kick HipHop 5	Hi-HatClosedT8 1	Timbale L	Stream *	Stream 2 *
	G7	G#7	SnareHipHopRim 4	Hi-Hat Open T8 1	Scratch H 3 *	Heart Beat *	Bubble 2 *
	A7	A#7	Snare HipHop 6	Hi-HatClosedT8 2	Scratch Down *	Foot Steps *	Bubble 2 *
	B7		Snare HipHop 11	Hi-Hat Open T8 2	Claves		
	C8	C#8	Kick HipHop 10	Hi-Hat Pedal Aco	Wood Block H		
	D8	D#8	Snare HipHop 7	Hi-HatClosed Aco	Wood Block L		
	E8		HipHop Clap 5	Hi-Hat Open Aco	Scratch H 2		
	F8	F#8	Conga H Tip	Hi-HatClosedLoFi	Scratch L 2		
	G8	G#8	Conga H Heel	Hi-HatOpen Lo-Fi	Triangle Mute		
	A8	A#8	Conga H Open	Hi-HatClosed Syn	Triangle Open		
	B8		Conga L Open 1	Hi-Hat Open Syn	Kick Break 3		
	C9	C#9	Conga L Open 2	Analog Shaker 1	Kick Break 4		
	D9	D#9	Kick HipHop 8	Tambourine RX5 2	Kick Break 5 *	Dog *	Dog *
	E9		HipHop Clap 6	Tambourine 1 Hit	Kick Break 6	Horse *	Horse *
	F9	F#9	Snare T8 1	Electric Cowbell	Kick Break 7	Bird Tweet *	Bird Tweet *
	G9	G#9	Snare T8 1 H	Conga T8 3	Hi-HatClosedBrk3	Explosion *	Firework *
	A9	A#9	HipHop Clap 7	ElectricTriangle	Snare Break 4		
	B9		Tom T8 1	Claves T8 2	Snare Break 5		
	C10	C#10	Hi-HatClosedT8 2	Analog Shaker 2	Snare Break 6	Ghost *	Ghost *
	D10	D#10	Tom T8 2	Electric Clap 1	Snare Break 7	Maou *	Maou *

*: Indicates an instrument which requires the Gate Time setting.

		SFX					
		Live! SFX Kit 2	Noise Kit	VocalEffectsKit	GospelAdLibs	Wonderland Kit	PopLatin Kit
Lower Keyboard	C-1						Cajon Low
	D-1	C#-1					Cajon Slap
	E-1	D#-1					Cajon Tip
	F-1						Claves High
	G-1	F#-1					Claves Low
	A-1						Hand Clap
	B-1	G#-1					
	A-1	A#-1					Finger Snap
	B-1						Castanet
	C0	C#0					Conga H Tip
	D0	D#0					Conga H Heel
	E0					Laser Beam	Conga H Open
	F0	F#0				Laser Shot *	Conga H Mute
	G0	G#0				Water Phone *	Conga H SlapOpen
	A0	A#0				Bubble	Conga H Slap
	B0					Puddle	Conga H SlapMute
	C1	C#1	Phone Call *	White Noise *	Male Ha 1 *	Thunder *	Conga L Tip
	D1	D#1	Door Squeak 2 *	Pink Noise *	Female Ha 1 *	Shower *	Conga L Heel
	E1		Door Slam 2 *	WhiteNoiseDown 1 *	Male Ha 2 *	Beach *	Conga L Open
	F1	F#1	Scratch Cut *	PinkNoise Down 1 *	Male Ha 3 *	Stream *	Conga L Mute
Upper Keyboard	G1	G#1	Scratch Split *	WhiteNoiseDown 2 *	Male Bh 1 *	Footstep	Conga L SlapOpen
	A1	A#1	Wind Chime *	PinkNoise Down 2 *	Female Bh 1 *	Door Squeak	Conga L Slap
	B1		Telephone Ring 2 *	White Noise Up 2 *	Male Kh 1 *	Door Slam	Conga L Slide *
	C2	C#2		White Noise Up 1 *	Female Kh 1 *	Bass Drum	Bongo H Open 1 f
	D2	D#2		Pink Noise Up *	Male Ph 1 *	Gran Cassa	Bongo H Open 3 f
	E2			WhiteNoiseUp Rel *	Female Ph 1 *	Tom 2	Bongo 2
	F2	F#2		PinkNoise Up Rel *	Male Th 1 *	Tom 1	Bongo H Tip
	G2	G#2		WhiteNoiseUp LFO *	Female Th 1 *	Snare	Bongo H Heel
	A2	A#2		PinkNoise Up LFO *	Male Bh 2 *	Snare Roll *	Bongo H Slap
	B2				Female Bh 2 *	Hi-Hat Closed	Bongo L Open 1 f
	C3	C#3			Male Ph 2 *	Cymbal	Bongo L Open 3 f
	D3	D#3			Female Ph 2 *	Hi-Hat Open	Bongo L Rim
	E3				Male Kh 2 *	Tambourine	Bongo L Tip
	F3	F#3			Female Kh 2 *	Finger Snap	Bongo L Heel
	G3	G#3			Male Bh 2 *	Castanet	Bongo L Slap
	A3	A#3			Female Bh 2 *	C'mon *	Timbale L
	B3				Male Ha 2 *	Hoo! *	
	C4	C#4			Female Ha 2 *	Aha! *	Wood Block L
	D4	D#4			Male Ha 3 *	Oh Yeah *	Triangle Open
	E4				Female Ha 3 *	Yayayayayah *	Wood Block H
	F4	F#4			Male Ph 3 *	Put Your Hands... *	Hand Clap
	G4	G#4			Female Ph 3 *	Jingle Bells	
	A4	A#4			Male Th 3 *	C'mon Now *	Paila L
	B4				Female Th 3 *	Bell Tree	Timbale H
	C5	C#5			Male Bh 3 *	Heeey *	Alarm Bell *
	D5	D#5			Female Bh 3 *	Everybody Now *	Train *
	E5				Male Ha 4 *	ClapYourHands... *	Horn 1 *
	F5	F#5			Female Ha 4 *	WithAllYourSoul *	Horn 2
	G5				Male Ha 5 *	Stand Up On... *	Siren *
					Female Ha 5 *	Uhh Yeah *	CarEngn Ignition *
					Male Kh 3 *	Aaah *	Car Crash *
					Female Kh 3 *	Come On! *	Helicopter *
					Male Ph 3 *	Yeah! *	Starship *
					Female Ph 3 *	Alright Now! *	Sheep *
					Male Th 3 *	One *	Goat *
					Female Th 3 *	Two *	Oxen *
					Male Bh 4 *	Three *	Whinny *
					Female Bh 4 *	Four *	Horse *
					Male Ph 4 *	One! *	Lion *
					Female Ph 4 *	Two! *	Dog
					Male Th 4 *	Three! *	Cat *
					Female Th 4 *	Four! *	Hen *
						Five! *	Owl *
						Six! *	Insects
						Seven! *	Frog
						Eight! *	Tweet 1
						Nine! *	Tweet 2 *
						Ten! *	Cuckoo Clock *
							Big Clock
							Bell *
							Telephone *
							Camera
							Gnaw
							Applause *
							Wind Chime

*: Indicates an instrument which requires the Gate Time setting.

		SFX				
		Cuban Kit	Arabic Kit	Turkish Kit	China Kit	OrchestraPerc
Lower Keyboard	C-1			Asma Davul L		Symphonic Gong 1
	D-1	C#-1		Asma Davul R		Symphonic Gong L *
	E-1	D#-1		Asma Davul Side		Symphonic Gong 2
	F-1			Asma Davul Both		Timpani E
	G-1	F#-1		KoltukDavul Flam		Timpani F
				KoltukDavul Teke		Timpani F#
	A-1	G#-1		Koltuk Davul Tek		Timpani G
				Koltuk Davul Dum		Timpani G#
	B-1	A#-1		Bendir Teke Flam		Timpani A
				Bendir Teke Dead		Timpani A#
	C0			Bendir Tek Dead	Da Cha 2	Timpani B
	D0	C#0		Bendir Teke	Da Gu mp	Timpani C
	E0	D#0		Bendir Tek	Da Gu Rim	Timpani C#
	F0	F#0		Bendir Slap	Da Gu f	Timpani D
	G0	G#0		Bendir Dum	Da Gu Hand	Timpani D#
	A0	A#0		Zil Right Close	Da Gu Roll *	Timpani High E
	B0			Zil Right Open	Pai Gu 4	Gran Cassa Hard
	C1	C#1		Zil Left Close	Pai Gu 4 High	Gran Cassa Soft
	D1	D#1		Zil Left Open	Pai Gu 3	Gran Cassa Hit
	E1			Tef Teke Flam	Pai Gu 3 High	Gran Cassa Cresc
	F1	F#1		Tef Tek Mute	Pai Gu 2	ConcertSnareDrum
	G1	G#1		Tef Teke Damped	Pai Gu 2 High	Snare Roll *
	A1	A#1		TefTekMuteMedium	Pai Gu 1	Snare Drum Light
	B1			Tef Dum Mute	Luo High 1	Snare Ensemble
	C2	C#2		Tef Cymbal	Gong Batter	Sus Cym 1 Roll S *
	D2	D#2		Tef Cymbal Mute	Jin Luo	Sus Cymbal 1
	E2			Tef Tremolo *	Luo High 2	Sus Cym 2 Roll L *
	F2	F#2		Tef Shake 1	Luo Mid-Low	Sus Cymbal 2
	G2	G#2		Tef Shake 2	Luo	Concert Tom 1
	A2	A#2		Tef Tek Flam	Jin Luo Low	OrchCymbal 1 ckd
	B2			Tef Full Open	Da Cha 1	Concert Tom 2
	C3	C#3		Tef Teke OpShort	Da Cha Effect	Orch Cymbal 1
	D3	D#3		Tef Tek Op Short	Zhongcha	Concert Tom 3
	E3			Xiaocha Effect	Xiaocha	Orch Cymbal 2
	F3	F#3		Tef Dum Open	Xiaocha	Concert Tom 4
	G3	G#3		Hollo FingerDead	Mang Luo Low	Concert Tom 5
	A3	A#3		Hollo Slap	Mang Luo Mid	Finger Cymbal
	B3			Hollo Dum	Qing	Gong
	C4	C#4		Kasik	Finger Bell	Ride Cymbal Tip
	D4	D#4		Kasik Flam	Luo Big	China Cymbal
Upper Keyboard	E4			Duhulla Dom	Muyu Low	Ride Cymbal Cup
	F4	F#4		BDarbuka TekDead	Muyu Mid-Low	Tambourine
	G4	G#4		BDarbuka TekFlam	Muyu Mid	Splash Cymbal
	A4	A#4		BDarbukaTekeFin1	Muyu High	Cowbell
	B4			BDarbukaTekeFin2	Nanbangzi Roll *	Jingle Ring
	C5	C#5		Bass Darbuka Tek	Nanbangzi	Castanet Roll *
	D5	D#5		BassDarbukaSlap1	Bangu	Table Castanet
	E5			BassDarbukaSlap2	Ban	Bongo H Stick
	F5	F#5		Bass Darbuka Dum	Bangu Roll *	Bongo L Stick
	G5			DarbukaRollClose *	ChineseOperaVo 1 *	Conga H Stick
				Darbuka RollOpen *	ChineseOperaVo 2 *	Conga L Stick
				DarbukaTekeFlamD	ChineseOperaVo 3 *	Whip
				Darbuka Tek Dead	Yunlao F	Rotating Tom 1
				DarbukaTekDamped	Yunlao F#	Tubular Bell L
				Darbuka TekeFlam	Yunlao G	Rotating Tom 2
				Darbuka Teke	Yunlao G#	Tubular Bell M

*: Indicates an instrument which requires the Gate Time setting.