


Huddle work instruction


Flashing PCB (Indoor camera)

- A). Double click on icon named “Flash” to open the program.
- B). Login by typing password =” **pivotedm1**”.
- C). Plugin Power, FPGA, and Tegra cables into PCB as shown on picture.
- D). Hold recovery button for 1 Sec and hold down reset button until fan stops. Then Let go of both buttons.
- E). Hit Enter on the laptop to start flashing, est. 9 minutes to complete the process.
- F). Unplug the Power, FPGA, and Tegra cables
- G). Remove the barcode Label


Open and Login



Connect cables to PCB



Flashing process



Remove Label

