




Installing Zscaler HW-1 Model Server

1. Rack the server using the included kit
2. Connect CAT6/Ethernet network cables according to the picture below
 - a) **IPMI Port** requires 100Mb connection, this port will not connect at 1Gb.
If you do not have 100Mb ports in your infrastructure we recommend purchasing and installing small factor, 100Mb supporting switch.
 - b) **OS/Management Port** connects at 1Gb
 - c) **Service Port** connects at 1Gb
3. Connect the power cable. Make sure the unit "powers on"
4. Upon successful installation notify Zscaler Operations team
5. Zscaler Operations team will verify connectivity and provision the server remotely
6. Zscaler Operations team will notify you via email on the completion of the configuration
7. Zscaler Support team will finalize the remaining options, testing plan, and production of the server



Power



**IPMI
Port**

**OS/Mgmt
Port**

**Service
Port**