





BUTTON MATRIX w/ WS2812B Backlight




External Reset Switch



Input for 2 Potentiometers



Caps for WS2812B (Keep close to LED)



Sheet: /		
File: DMX_MIDI_FIGHTER.kicad_sch		
Title:		
Size: A3	Date:	Rev:
KiCad E.D.A. 8.0.6		Id: 1/1