




## Printer Interface




## Camera Interface




## LCD/SD Card Interface




## WiFi Interface




## TM4C123 Oscillator/Power



## Power Input



## Power 3.3V



## Button Interface

