




How to download part of bitmap font to printer

1. Open [Diagnostic Tool] and enter the tab [Bitmap Font Manager]
 - 1.1 Choose the interface.
 - 1.2 Set [Font Encoder] as [Encode by Table (Asian)].
 - 1.3 In box Encode by table, type the words that you want to download to printer. (Ex. 一二三四五)
 - 1.4 Click the button [Select Font] to select the Chinese true type font and click [OK].







2. Name the printer font name, and then you can use this font name to print the traditional Chinese characters. Click the button [Download Font] to start generating and downloading the bitmap fonts.



2.1 Generating bitmap font.



2.2 Downloading bitmap font.



3. Enter the tab [Command Tool] and type in printer commands to print the traditional Chinese characters.

