

Name	PM_{Block}		
Kind	RequiredPort	Interface	NvMMirror
Description	--		
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()

8.2.3.3 NvM_PNIB_{Block}

[SWS_NvM_00845] [

Name	PNIB_{Block}		
Kind	RequiredPort	Interface	NvMNotifyInitBlock
Description	--		
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()

8.2.3.4 NvM_PNJJF_{Block}

[SWS_NvM_00846] [

Name	PNJJF_{Block}		
Kind	RequiredPort	Interface	NvMNotifyJobFinished
Description	--		
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()

8.2.3.5 NvM_PS_{Block}

[SWS_NvM_00847] [

Name	PS_{Block}		
Kind	ProvidedPort	Interface	NvMService
Description	--		
Port Defined Argument Value(s)	Type	NvM_BlockIdType	
	Value	{ecuc(NvM/NvMBlockDescriptor/NvMNvramBlockIdentifier.value)}	
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()