

QMK program


simple: PAUSE ----DEL


open <http://qmkeyboard.cn/>

Or choose a preset layout
选择默认布局


DZ60标准配列
DZ60HHKB
DZ60(2xSHIFT)
DZ60带方向配列
JC65
KEYCLACK65 V1
KBD75
DZ44
DZ44(planck)

2 click pause





ok, layout is modify download layout




5




install software ,

6 PCB get into BootLoader mode


fn+backspace or There is a rest button below the PCB




or




7. install drive













8 update hex









complete