

Program #	Name	Description
01	ALL OFF	All Channels and masters = MUTED for setup changing
02	Piano 001	Piano = 14, Vocal = 10
03	Piano 002	Add Flute on 9
04	Piano 003	Add Cantor on 11
05	Piano 004	Add Wireless # 2 on 17
06	Guitar 001	Normal per setup sheet for Don
07	Guitar 002	
08	Guitar 003	
09	Guitar 004	Normal per setup sheet for James
10	Guitar 005	
11	Mike B 001	Normal - Vocal = 7, 10 Guitar = 28
12	Mike B 002	Add 8 & 11 for vocalists
13	Mike B 003	Add 12 & 29 for second guitarist
14	Mike B 004	Thanksgiving 001
15	Mike B 004	Thanksgiving 002
16	Caritas 001	Normal - per setup diagram
17	Caritas 002	
18	Caritas 003	
19	Caritas 004	
20	Caritas 005	
21	Children 001	Normal - per setup diagram
22	Children 002	
23	Children 003	
24	Chorus 001	Normal - per setup diagram
25	Chorus 002	
26	Phanxico 001	Normal per setup sheet
27	Phanxico 002	
28	Phanxico 003	
29	Phanxico 004	
30	Phanxico 005	
31	Youth 001	Normal per setup sheet
32	GYV 002	
33	GYV 003	
34	GYV 004	
35	GYV 005	
36	Wentz 001	Normal per setup sheet
37	Wentz 002	Add Roger vocal + guitar
38	Wentz 003	Add Piano on 14
39	Wentz 004	
40	Wentz 005	

Program #	Name	Description
41	AFG 001	Normal per setup sheet
42	AFG 002	
43	AFG 003	
44	AFG 004	
45	AFG 005	
46	AFG 006	
47	AFG 007	
48	AFG 008	
49	AFG 009	
50	AFG 010	
51	Wedding 001	
52	Wedding 002	
53	Wedding 003	
54	Wedding 004	
55	Wedding 005	
56	Wedding 006	
57	Wedding 007	
58	Wedding 008	
59	Wedding 009	
60	Wedding 010	
61	Special 001	
62	Special 002	
63	Special 003	
64	Special 004	
65	Special 005	
66		
67		
68		
69		
70		
71		
72		
73		
74		
75		
76		
77		
78		
79		
80		

POWER ON Procedure

1. Setup Mics & monitors, etc

Always plug in mics, etc. before turning on main power when you are the first user of the day.

2. Power up Equipment.

Turn on Main power switch located on top left section of rack if you are the 1st user of the day. This will sequence on all of the equipment.

If the equipment is already in use, Push "**MUTE 1**" to turn off all channels. Red mute lights go on. Then rearrange mics, etc.

3. Snapshot Recall Procedure

Push "**snapshot**" button located next to LCD display. Button lights up green.

Turn rotary "**Parm**" control under LCD to desired snapshot # (flashing = active).

Push "**Recall**" located under LED display to restore mixer to previous saved configuration.

4. Turn on mixer

After group has finished setting up all instruments & mics:

Push **MUTE 1** to activate all channels & master section. Red mute lights go out.

5. Power off

LEAVE main system power on if it will be used again later that day.

If the sound system will be used again **soon** :

Push "**MUTE 1**" to turn off all channels. Red mute lights go on.

If the sound system will be used again **later that day** :

Push "**MUTE 1**" to turn off all channels. Red mute lights go on.

Push and HOLD "**LOCK**" button until all lights go out. This prevents tampering while the sound system is unattended.

OR - Turn off Main power switch located on top left section of equipment rack.

NOTE: ALWAYS push "MUTE 1" before turning the system off ,changing snapshot #, or plugging or unplugging mics.

This will insure that the next time that the system is powered up it will have "MUTE 1" on.

This will prevent damaging the speakers!

LOCK Procedure

Push and hold "lock" button located next to LED display.

Console turns off all lights except LCD display, and moves all faders to bottom, BUT REMAINS IN normal OPERATION.

Prevents tampering during unattended operation.

UNLOCK Procedure

Push and hold "lock" button located next to LED display.

Console unlocks and returns to previous settings and moves all faders to previous locations.

Snapshot #	NAME	Description
01	ALL OFF	All Channels and masters = MUTED for setup changing
02-05	Piano/Ray/Steve	Piano = 14, Vocal = 10
06-08	Alich	Normal per setup sheet
09-10	O'Connell	Normal per setup sheet
11-15	Buchner	Normal per setup sheet
16-20	Caritas	Normal per setup sheet
21-23	Children	Normal per setup sheet
24-25	Chorus	Normal per setup sheet
26-30	Panxico	Normal per setup sheet
31-35	GYV	Normal per setup sheet
36-40	WENTZ	Normal per setup sheet
41-50	AFG	Normal per setup sheet
51-60	Wedding	Normal per setup sheet
61-70	Special	Ocassional special setups