

TypeError: Cannot read properties of undefined (reading 'id') (Issue [#282](#))

Here's my configuration

```
{
  "name": "InsteonLocal",
  "user": "LoreeXXX",
  "pass": "XXXXXXXX",
  "host": "192.168.1.XX",
  "port": "25105",
  "model": "2245",
  "refresh": "0",
  "server_port": "3000",
  "keepAlive": "3000",
  "devices": [
    {
      "name": "2nd Floor Hall Motion Sensor",
      "deviceId": "41.68.3C",
      "dimnable": "FALSE",
      "deviceType": "motionsensor"
    },
    {
      "name": "Aaron Nightstand Light",
      "deviceId": "3B.09.05",
      "dimnable": "true",
      "deviceType": "lightbulb"
    },
    {
      "name": "AJ AV",
      "deviceId": "1B.67.D3",
      "dimnable": "FALSE",
      "deviceType": "outlet"
    },
    {
      "name": "AJ Ceiling Light",
      "deviceId": "4C.11.C7",
      "dimnable": "true",
      "deviceType": "lightbulb"
    },
    {
      "name": "AJ Nightstand Light",
      "deviceId": "2C.11.53",
```

```
"dimmable": "true",
"deviceType": "lightbulb"
},
{
  "name": "AJ Reading Light",
  "deviceId": "3B.08.DF",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "AJ xBox",
  "deviceId": "49.33.7C",
  "dimmable": "FALSE",
  "deviceType": "switch"
},
{
  "name": "Andrea Nightstand Light",
  "deviceId": "3B.09.07",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Back Porch Light",
  "deviceId": "2B.98.17",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Basement Door Sensor",
  "deviceId": "4D.DC.DF",
  "dimmable": "true",
  "deviceType": "doorsensor"
},
{
  "name": "Basement Stairs Light Switch",
  "deviceId": "19.36.3F",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Basement Stairs Lower Switch",
  "deviceId": "0E.5C.E9",
  "dimmable": "true",
  "deviceType": "lightbulb"
}
```

```
},
{
  "name": "Book Barn Door Sensor",
  "deviceId": "36.F1.2A",
  "dimnable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "CO Smoke Bridge Sensor",
  "deviceId": "47.4C.8E",
  "dimnable": "FALSE",
  "deviceType": "smoke"
},
{
  "name": "Deck Flood Lights",
  "deviceId": "48.77.8D",
  "dimnable": "FALSE",
  "deviceType": "lightbulb"
},
{
  "name": "Gazebo Lights",
  "deviceId": "4E.01.1C",
  "dimnable": "FALSE",
  "deviceType": "lightbulb"
},
{
  "name": "Dining Room Ceiling Light",
  "deviceId": "56.D4.17",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Family Room Floor Lamp",
  "deviceId": "49.F5.36",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Family Room Left Table Light",
  "deviceId": "23.5C.09",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  }
```

```
"name": "Family Room Motion Sensor",
"deviceId": "41.60.76",
"dimmmable": "FALSE",
"deviceType": "motionsensor"
},
{
  "name": "Family Room Floor Step Light",
  "deviceId": "18.C1.0E",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Family Room Right Table Light",
  "deviceId": "35.18.E6",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Fireplace Lights",
  "deviceId": "1A.64.64",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "First Floor Hall Ceiling Light",
  "deviceId": "1A.65.1E",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "First Floor Hall Light Switch",
  "deviceId": "19.3F.BA",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Front Door Sensor",
  "deviceId": "11.BB.71",
  "dimmmable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Front Porch Lights",
  "deviceId": "1A.5E.E8",
```

```
"dimmable": "true",
"deviceType": "lightbulb"
},
{
  "name": "Garage Ceiling Lights",
  "deviceId": "25.6A.B6",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Garage Interior Door Sensor",
  "deviceId": "21.C8.D1",
  "dimmable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Garage Outside Front Lights",
  "deviceId": "1B.87.B1",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Garage Outside Side Light",
  "deviceId": "45.30.5F",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Garage Side Entry Door Sensor",
  "deviceId": "2D.4C.A3",
  "dimmable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Garage Side Entry Flood Light",
  "deviceId": "2F.D1.22",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Grill Lights",
  "deviceId": "4E.02.00",
  "dimmable": "true",
  "deviceType": "lightbulb"
}
```

```
},
{
  "name": "Guest Bath Sink Leak Sensor",
  "deviceId": "53.13.B6",
  "dimnable": "true",
  "deviceType": "leaksensor"
},
{
  "name": "Guest Bath Toilet Leak Sensor",
  "deviceId": "53.13.D5",
  "dimnable": "true",
  "deviceType": "leaksensor"
},
{
  "name": "Guest Room Ceiling Light",
  "deviceId": "1F.D2.D2",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Guest Room Nightstand Light",
  "deviceId": "3B.08.D3",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Hall Picture Light",
  "deviceId": "2C.14.09",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Holiday Family Room Tree Light",
  "deviceId": "37.40.08",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Holiday Living Room Tree Light",
  "deviceId": "4E.49.C7",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  }
```

```
"name": "Holiday Mantel Lights",
"deviceId": "35.62.BD",
"dimmmable": "true",
"deviceType": "lightbulb"
},
{
  "name": "Holiday Porch Lights",
  "deviceId": "40.11.40",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Holiday Theate Room Tree Light",
  "deviceId": "49.2D.2E",
  "dimmmable": "false",
  "deviceType": "lightbulb"
},
{
  "name": "Hotwater Heater Leak Sensor",
  "deviceId": "28.06.28",
  "dimmmable": "false",
  "deviceType": "leaksensor"
},
{
  "name": "Kitchen Cabinet Lights",
  "deviceId": "49.33.F4",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Kitchen Ceiling Lights",
  "deviceId": "58.18.66",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Kitchen Island Lights",
  "deviceId": "50.2A.E3",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Kitchen Pantry Door Sensor",
  "deviceId": "45.D1.11",
```

```
"dimmable": "FALSE",
"deviceType": "doorsensor"
},
{
  "name": "Kitchen Table Light",
  "deviceId": "3D.10.A7",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Kitchen Under Sink Leak Sensor",
  "deviceId": "40.3C.D7",
  "dimmable": "FALSE",
  "deviceType": "leaksensor"
},
{
  "name": "Kitchen Window Light",
  "deviceId": "56.7F.28",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Laundry Door Sensor",
  "deviceId": "28.44.EC",
  "dimmable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Laundry Room Leak Sensor",
  "deviceId": "49.20.C6",
  "dimmable": "FALSE",
  "deviceType": "leaksensor"
},
{
  "name": "Laundry Room Light",
  "deviceId": "45.90.49",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Laundry Room Switch",
  "deviceId": "50.A3.88",
  "dimmable": "true",
  "deviceType": "lightbulb"
}
```



```
},
{
  "name": "Living Room Floor Light",
  "deviceId": "15.2B.F5",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Living Room Motion Sensor",
  "deviceId": "41.6D.C2",
  "dimnable": "FALSE",
  "deviceType": "motionsensor"
},
{
  "name": "Lower Office Ceiling Light",
  "deviceId": "33.06.52",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Lower Office Desk Light",
  "deviceId": "01.24.CB",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Lower Office Door Sensor",
  "deviceId": "36.E6.0B",
  "dimnable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Lower Office Rope Light",
  "deviceId": "35.44.9B",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Mailbox Sensor",
  "deviceId": "36.DE.09",
  "dimnable": "FALSE",
  "deviceType": "doorsensor"
},
{
  }
```

```
"name": "Master Bath L Sink Leak Sensor",
"deviceId": "53.14.5A",
"dimmmable": "FALSE",
"deviceType": "leaksensor"
},
{
  "name": "Master Bath R Sink Leak Sensor",
  "deviceId": "53.12.5E",
  "dimmmable": "FALSE",
  "deviceType": "leaksensor"
},
{
  "name": "Master Bath Sink Lights",
  "deviceId": "56.7E.08",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Master Bath Toilet Leak Sensor",
  "deviceId": "53.14.4E",
  "dimmmable": "FALSE",
  "deviceType": "leaksensor"
},
{
  "name": "Master Bedroom Ceiling Light",
  "deviceId": "20.41.97",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Office Floor Lamp",
  "deviceId": "49.30.B4",
  "dimmmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Patio Door Sensor",
  "deviceId": "21.C8.DC",
  "dimmmable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Pergola Lights",
  "deviceId": "40.11.E9",
```

```
"dimmable": "true",
"deviceType": "lightbulb"
},
{
  "name": "Pool Interior Lights",
  "deviceId": "17.DE.10",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Pool Overhead Lights",
  "deviceId": "50.A3.A7",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Poolhouse Flood Light",
  "deviceId": "53.88.9F",
  "dimmable": "FALSE",
  "deviceType": "lightbulb"
},
{
  "name": "Poolhouse Front Door Lights",
  "deviceId": "48.7F.F4",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Poolhouse Front Door Sensor",
  "deviceId": "36.DC.C5",
  "dimmable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Poolhouse Left Light",
  "deviceId": "2C.13.0C",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "PoolHouse Office Ceiling Fan",
  "deviceId": "3F.8B.7A",
  "dimmable": "FALSE",
  "deviceType": "fan"
```

```
},
{
  "name": "Poolhouse Office Ceiling Light",
  "deviceId": "1B.9A.AA",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Poolhouse Office Desk Fan",
  "deviceId": "19.7F.83",
  "dimnable": "FALSE",
  "deviceType": "switch"
},
{
  "name": "Poolhouse Office Left Light",
  "deviceId": "2B.C6.0C",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Poolhouse Right Light",
  "deviceId": "2C.12.63",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Poolhouse Side Door Light",
  "deviceId": "3C.46.7A",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Poolhouse Side Door Sensor",
  "deviceId": "36.DB.D2",
  "dimnable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Powder Room Leak Sensor",
  "deviceId": "53.13.CA",
  "dimnable": "FALSE",
  "deviceType": "leaksensor"
},
{
  }
```

```
"name": "Second Floor Hall Light Switch",
"deviceId": "1A.5E.61",
"dimnable": "true",
"deviceType": "lightbulb"
},
{
  "name": "Second Floor Hall Lights",
  "deviceId": "51.79.4A",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Second Floor Hall Table Light",
  "deviceId": "35.48.27",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Shed Door Sensor",
  "deviceId": "3F.6C.03",
  "dimnable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Sump Pump Leak Sensor",
  "deviceId": "40.3C.A6",
  "dimnable": "FALSE",
  "deviceType": "leaksensor"
},
{
  "name": "Theater Room Cabinet Lights",
  "deviceId": "26.E6.4C",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Theater Room Ceiling Lights",
  "deviceId": "0E.58.B4",
  "dimnable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Theater Room Floor Lamp",
  "deviceId": "3E.95.55",
```

```
"dimmable": "true",
"deviceType": "lightbulb"
},
{
  "name": "Theater Room Table Light",
  "deviceId": "26.DD.11",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Upper Office Ceiling Light",
  "deviceId": "20.43.4A",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Upper Office Desk Light",
  "deviceId": "1A.C9.71",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Upper Second Floor Hall Keypad",
  "deviceId": "4C.77.33",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Utility Room Ceiling Light",
  "deviceId": "48.A9.EB",
  "dimmable": "true",
  "deviceType": "lightbulb"
},
{
  "name": "Utility Room Door Sensor",
  "deviceId": "36.E4.AE",
  "dimmable": "FALSE",
  "deviceType": "doorsensor"
},
{
  "name": "Poolhouse Office Right Light",
  "deviceId": "2c.14.2c",
  "dimmable": "true",
  "deviceType": "lightbulb"
}
```

```
  },
  {
    "name": "Kitchen Floor Cabinet Light",
    "deviceId": "4E.4D.64",
    "dimnable": "true",
    "deviceType": "lightbulb"
  },
  {
    "name": "Poolhouse Office AC/Heater",
    "deviceId": "08.28.91",
    "dimnable": "false",
    "deviceType": "switch"
  },
  {
    "name": "Garage Door Sensor",
    "deviceId": "37.05.C1",
    "dimnable": "false",
    "deviceType": "doorsensor"
  },
  {
    "name": "Kitchen Motion Sensor",
    "deviceId": "41.5E.67",
    "dimnable": "false",
    "deviceType": "motionsensor"
  }
],
"_bridge": {
  "username": "0E:AD:DB:6F:AC:AC",
  "port": 56513
},
"platform": "InsteonLocal"
}
```