



0.96 inch OLED for Arduino IIC-interface

operating instructions


- 1> [uncompress](#) U8glib.zip and Copy it to the arduino library directory; **As shown below**



- 2> [opened-file](#) U8glib\examples



- We can Choose any one file, for example



- ◆ We chose U8GLIB_SSD1306_128X64 u8g(U8G_I2C_OPT_NONE); // I2C / TWI 选择这个类
- ◆ Remove the front / /

- ◆ 4 [compile](#) and [download](#)
- ◆ 5> [connection type](#)
- ◆ Aduino board OLED [display](#)
- ◆ GND GND
- ◆ 3.3V or 5V VCC
- ◆ A4 D1 (SDA FOR IIC)
- ◆ A5 D0 (SCL FOR IIC)

