

INSTALLATION PRECAUTIONS:

1. Please refer to the instruction manual for electrical application, wrong operation will cause damage to the unit.
2. This unit shall be installed by professional personnels, if possible.
3. Insulate all exposed wires to avoid short circuit.
4. Apply the power cord after all connections of the unit are set.
5. The unit is designed for 12V-14.4V negative, ground operation system only, make sure your vehicle is connected to such negative ground electrical system.

SPECIFICATIONS:

RADIO:

FM Frequency range.....87.5-108MHz
Signal/Noise ratio.....>60dB


USB/SD (SD Optional) :

Frequency response.....20Hz-20KHz
Signal/Noise ratio.....>60dB
T.H.D<3%(1KHz)

Others:

MAX Output power.....4*50W
Supply voltage.....DC:12-14.4V(10A)
Speaker impedance4-8ohm/CH

WIRING CONNECTIONS:



A1: FL SPEAKER+(White)
A2: RR SPEAKER-(Purple black)
A3: FL SPEAKER-(White black)
A4: RR SPEAKER+(Purple)
A5: FR SPEAKER+(Gray)
A6: RL SPEAKER+(Green)
A7: FR SPEAKER-(Gray black)
A8: RL SPEAKER-(Green black)
A9: KEY1 Steering wheel control
A10: Auto antenna
A11: Car reversing control wire
A12: KEY2 Steering wheel control
A13: ACC wire(Red)
A14: ILLUMINATE control wire
A15: GROUND(Black)
A16: B+ POWER wire(Yellow)

B1/B2: MIC-/MIC+ (Optional)
B3: VIDEO-IN2(Yellow/Optional)
B4: VIDEO-IN 1(Yellow)
B6: SUB-OUT(Optional)
B8: VIDEO-OUT(Yellow/Optional)
B15/17: AUX-IN L/R (White/red)
B16/18: RCA-OUT L/R (White/red)
B19: Amplifier control wire
C: REAR USB 1
D: REAR USB 2
E1: Handbrake control wire(Optional)
E2: WiFi antenna
E3: Back Cam Power(Optional)
E6: CAM-IN (Yellow)
E10: BT antenna






This terminal cable must be connected, otherwise it will affect the signal strength of WiFi and Bluetooth.

COMMON FUNCTION BUTTONS:


   : Setting Menu

   : APP Menu


   : Return to the main menu



   : Return to the previous menu


LOCAL MUSIC:

 : Playlist , You can choose your favorite music.


 : Loop Play Mode Switching


  : Last song/next song


  : Pause/Play


 : Sound settings

LOCAL RADIO:

  : Up/down search station, no search station will terminate search


 : Band Conversion


 : save radio stations

 : Conversion of LOC/DX functions

*You can pull the scale bar or radio station number to choose your favorite station.



Common functions of drop-down menu:

 External power amplifier control switch function.

 The system has its own screen capture function. Screen capture pictures can be found in File Manager.


 External video output function switch.


BLUETOOTH:





* Open the Bluetooth function of the mobile phone, click on the corresponding device name to connect, and connect the password "0000".



 : Enter Bluetooth Dial-up Keyboard.



 : Phone book function

 : Call record

 : Bluetooth Function Settings

 : Bluetooth music

  : Last song/next song

  : Pause/Play

Other commonly used APPs



App store , Click on the "Play Store" icon to go to the Google Play Store to download the app (WiFi must be connected).



Web browser, click the home page "Chrome" icon to enter, enter the network address to browse the corresponding web page.



Navigation applications, more navigation applications can be downloaded from Play Store.



File management, internal files and USB copy / delete operations.




Local video playback, support MP4/AVI/RMVB... Wait for video format.




External input, supporting external audio/video input function.



More detailed instructions can be found in these. 

SOUND SETTINGS:




* This menu can adjust multiple sound modes for treble, baritone and bass

: Adjust front, rear, left and right channel balance

: Restore to default settings

FACTORY SETTINGS:





* Settings Password: 8888



Non-professionals are not allowed to change the internal settings at will, otherwise they can affect the normal use.

.7.

ANDROID SETTINGS:



Wi-Fi :

*Click to enter the WIFI settings, Select the WIFI account and enter the WIFI password to connect.



Display :

*Click to enter the predetermined wallpaper settings, or you can choose your favorite wallpaper by USB.



Language & input :

*Android Language Settings.



Date & time :

*System date and time settings.




Backup & reset :

*Access to restore factory settings.

.8.


VOLUME SETTINGS:



* Set the media volume, Bluetooth voice volume, GPS mixing ratio.

- ⏪ Set the media volume size.
- ⏪ Bluetooth voice volume size.
- ⏪ GPS mixing ratio size.


STEERING LEARN:



* Setting the Steering Wheel Control Function Key.

1. Functional keys as needed.
2. Press the corresponding function button on the steering wheel.
3. The prompt "Setup success" indicates that the setup was successful.

LOGO SETTINGS:




* You can set your favorite logo as boot LOGO, You can choose your favorite LOGO through USB.

Note:

The supported LOGO must be in 1024*600 24b BMP format.

OTHER SETTINGS:



- ⏪ Suspension ball function switch.
- ⏪ Handbrake set switch.
- ⏪ Force setting to horizontal screen.
- ⏪ Reversing mute setting.