

280

260

240

220

200

180

160

140

120

100


80

60

40

20

0



Hello World!

Scale is to calibrate actual printed dimension. Check both X and Y. Measure between tick 0 and last tick