



## English

Thank you for purchasing the UGREEN products. For optimum operation, please read this manual carefully before use.

### Product Details



### How It Works



#### Connect and Pair for the First Time

1. Connect the 3.5mm plug to your computer or TV.
2. Use the provided Micro USB cable to power this unit and it will turn on automatically and ready to be paired.

- 1 -

3. Keep your Bluetooth headphone or speaker in the transmitting range of 10m and turn on your Bluetooth headphone or speaker. This unit will automatically pair with your device.
4. Play music on your computer or TV and start to enjoy wireless audio.
5. When you restart this unit next time, it will reconnect to this Bluetooth device automatically.

#### Two-point Connection Function

This unit can connect two Bluetooth devices at the same time and we take device A and device B as an example.

1. Make sure the distance between two Bluetooth devices should not exceed 5 meters.
2. Pair this unit with device A as mentioned above and TURN OFF device A.
3. Double click the button to enter pair mode and turn on device B. This unit will automatically pair with device B.
4. Turn on device A and this unit will re-connect with device A.
5. Play music on your computer or TV. Now you can share wireless audio with your friend.
6. When you **restart** this unit next time, it will reconnect to this two connected **devices** automatically.

#### Button Function

- Double-click the button to enter the pair mode if you want to pair with another Bluetooth device.
- If you are out the transmit range of 10m for more than five minutes, click the button to re-connect your device when back to the effective range.
- Long press the button for 3 seconds to turn on or turn off this unit under the condition of power supply.
- Long press the button for 10 seconds and you can reset the unit to factory settings with blue light on for 2.5sec.

- 2 -

### Notes

1. This unit can only transmit audio from computer/TV to your Bluetooth headphone/speaker and cannot connect computer/TV to your mobile phone.
2. This unit cannot control volume and play/pause music.
3. This unit can work with UGREEN Bluetooth audio receiver.

### Safety Notes

1. Works with  $5V \pm 5\%$  power supply, exceeding range of standard voltage may cause damage to the product or lead to unintended safety problems.
2. The unit should not be placed near the magnet or products with a strong magnetic field, which will affect the normal function of the unit or damage the unit.
3. Avoid using this unit in extreme high or low temperatures and humid environments.
4. The unit is radio signal. Please make sure there is no other signal interference.
5. To prevent possible hearing damage, do not listen at high volume levels for long periods.
6. Do not modify, repair or disassemble the unit, if so, please contact the manufacturer.

### Package Contents

- 1x Bluetooth Audio 5.0 Transmitter
- 1x Micro USB Cable
- 1x User Manual

- 3 -

### FAQ

1. **A:** Unable to pair or unsuccessful pairing after turning on the device for the first time?  
**Q:** The Bluetooth receiver device enters the pairing status again, and then double-clicks the button to enter the pairing pattern.
2. **A:** There is no sound or the sound doesn't come from the device after pairing the Bluetooth?  
**Q:** Please be sure that whether inserted the product in the output ports (TV/Computer);
  - This product requires power when working, so please power it by the matched cable;
  - If the sound does not come from the device after connection, please set it as follows,
    - Connecting TV: In the audio settings of the TV, set the audio output to analog audio output .
    - Connecting Computer: Place the mouse on the right lower corner of the computer and click the right mouse button - Sound - Play - Choose your own speaker as the default device.

### Disposal



The packaging is made entirely of recyclable materials, which you may dispose of at local recycling facilities.

Contact your local refuse disposal authority for more details of how to dispose of your worn-out product.



To help protect the environment, please dispose of the product properly when it has reached the end of its useful life and not in the household waste. Information on collection points and their opening hours can be obtained from your local authority.

Faulty or used batteries must be recycled in accordance with Directive 2006/66/EC. Please return the batteries and/or the device to the available collection points.

- 4 -