


PIN 5 IS LEFT IN 'HIGH Z' IN RUN SATE. THIS LINE WILL FEED THE BUS CONNECTOR,
RESET LOGIC FROM CONNECTOR SHOULD BE OPEN COLLECTOR.



TITLE: SBC CONTROLLER		REV: 1.0
Company: Z8D		Sheet: 1/1
Date: 2025-07-02	Drawn By: dave collins	