

Power & Filters

File: Power&Filter.kicad_sch

CPU-ROM-RAM

File: CPU-ROM-RAM.kicad_sch

EPM7128S

File: EPM7128S.kicad_sch

VideoEarMic

File: Video.kicad_sch

Joystick

File: Joystick.kicad_sch

Turbo Sound

File: Turbo S0und.kicad_sch

SAA1099

File: SAA1099.kicad_sch

Midi

File: Midi.kicad_sch

PlusD

File: PlusD.kicad_sch



MountingHole



MountingHole



MountingHole



M4 MountingHole



MountingHole



MountingHole

Sheet: /
File: ZX Max 128 PlusD Issue1.kicad_sch

Title:


Size: A4

Date:

Rev:

KiCad E.D.A. 9.0.7

Id: 1/10



Sheet: /Power & Filters/
File: Power&Filter.kicad_sch

Title:


Size: A4

Date:


KiCad E.D.A. 9.0.7


Rev:

Id: 2/10









Sheet: /Joystick/
File: Joystick.kicad_sch


Title:

Size: A4
KiCad E.D.A. 9.0.7

Date:

Rev:

Id: 6/10



Sheet: /Turbo Sound/
File: Turbo S0und.kicad_sch

Title:


Size: A4


Date:

KiCad E.D.A. 9.0.7

Rev:

Id: 7/10





Sheet: /Midi/ File: Midi.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. 9.0.7		Id: 9/10

