



RPi Voltage Regulator



This regulator provides 5V for the RPi. The user must modify a micro-USB cable to interface with this board.

Pump Header



This low side driver controls the pump. R2 pulls the pump high to Vin (12V). Pump_On is held low until pulled high by logic-high from the RPi.

RPi GPIO Header

