




## Raspberry PI 2 40 PIN CONNECTOR



## ARDUINO STD CONECTORS



### Arduino ONLY:

Serial D0 (rx) & D1 (tx)

Serial D2 (rx) & D3 (tx)

## RN2xx3 Raspberry Pi (2) & Arduino Expansion

- rPi:
- RN tx/rx connected to pins 8-10 of conn RPI
  - RN reset connected to pin 37 of conn RPI
  - RN 3V power from rPi . OPEN J7 !!

## Arduino

- RN tx/rx can be selected (D0/D1 or D2/D3)
- RN reset connected to D13
- RN 3V power from regulator. Close J7