



Cabin Door



**Mid-Cabin Door**

**Operation**

F/As must not open/close doors, except for emergency situations.

**Exterior**

- Push the flap and grasp the Door Control Handle
- Fully lift up the Door Control Handle
- Pull the door outward and forward until the Gust Lock engages
- Lower the Door Control Handle into the recess

**Note:** Use the reverse procedure for closing from the exterior.