

■ Stop Mode

Shows fixed time. ( Initial state : '00:00:00.00')


No blinking



■ Timer Mode

Shows current time. (increment)

Blinking



■ Midtime Mode (Initial)

Shows midtime when 'MID' is on.

Blinking (Timer continues.)



■ Midtime Mode (2nd time or later)

Shows midtime when 'MID' is on.

Blinking (Timer continues.)



■ Split (Lap) Mode

Shows difference between last two midtimes.

Blinking (Timer continues.)

