


WEATHERTHING

1



WiFi: WeatherThing_xxxx
Password: weatherthing

2



3



WIFI SETUP REQUIRED

Connect to your home WiFi to use the weather display!

NETWORK NAME (SSID)

YourWiFiName

PASSWORD

.....

SAVE WIFI SETTINGS

4

http://192.168.1.123
OR
http://weatherthing.local

QUICK SETUP

Configure these essential settings first for best experience!

Location

Current: 56.9496, 24.1052 (Default: Riga, Latvia)

Enter city name OR 56.949 24.105

WiFi

Connected to: MakeRiga (IP: 192.168.88.132)

Network name (SSID) Password

Timezone

Current: GMT+2 (Default: GMT+2 Riga)

GMT+2 (Riga, Helsinki)

SAVE QUICK SETUP



Github: <https://github.com/makeriga/weatherthing-firmware>

Firmware update/Programmatūras atjauninājumi: <https://makeriga.github.io/weatherthing-firmware/>

Email/E-pasts: hello@makeriga.org

Factory reset: hold top finger button + insert usb

Recovery: short "BOOT" jumper on circuit board, use updater

Rūpnīcas iestatījumi: turi augšas pirksta pogu + iespraud USB

Atkopšana: savieno "BOOT" uz plates + iespraud USB, atjauno programmu

Nodibinājums "ATVĒRTĀ DARBŅĪCA MAKE RĪGA"

Reg: LV40008230679

EDI, DZERBENES 14, RIGA, LV1006, LATVIA

