



HOW TO USE WITH ARDUINO

| | | | |
|--|--|--------------------|----|
| SWITCH DEBOUNCER | | VCC: 2-6V | |
| WWW.NIXIETESTER.COM | | Design: Marcin Saj | |
| Date: 18 FEB 2023 | | Sheet: 1/1 | V1 |