



VCC & ALL PINS VOLTAGE LEVEL: 3.3V - 5V

■ CLK MUST BE CONNECTED TO THE ARDUINO SCK PIN (SPI), DIN TO THE MOSI PIN (SPI)

■ EN CAN BE CONNECTED TO ANY ARDUINO DIGITAL PIN

■ MUST BE CONNECTED TO ANY PWM ARDUINO PIN

IF THE PWM OPTION IS NOT USED THEN IT CAN BE CONNECTED TO ANY ARDUINO DIGITAL PIN

□ DOUT IS NOT CONNECTED

WWW.NIXIETESTER.COM