


Electrical harness changes


- ↳ Add additional sensor for aux washdown pump
- ↳ add level sensor in Solids Box

Program changes -

Unloader - AUX Washdown Pump



Solids box Level Sensor Pump Control



The System will monitor both level sensors and the pressure transducer

If L₁ is high and L₂ is Low for some time then Screen is Blocked

If L₂ is high and SI PSI is Low for some time pump is faulted

Make memo for Bill