

Connect your PC to your Arduino Yun with wi-fi network. Then open “192.168.240.1” local address in browser. Default password is: “doghunter”. Configure your wireless network and password. Then click “CONFIGURE & RESTART”.

