



Headers




SJ1: select address of Eeprom
 SJ2: enable/disable external Antenna
 SJ3: select address of Movement Sensor
 SJ4: select address of Temperature Sensor




I2C, Reset and Push Pullups




Analog Light




E2PROM




MCU




Radio




Antenna Tuning




Light intensity




Movement



Temperature / Humidity



Light UV



Light RGB