

# User documentation

Martin Münch, Marcel Ouška

20. 5. 2014

## 1 Device description

As you can see on picture, device is composed only from keyboard and LCD display. It's main purpose is to provide security system for door.




Figure 1: Device

When you access door with this device, you will see on display “INSERT ID”. After you write your ID, push key OK. Next you are asked to “INSERT PIN”, after inserting pin, push key OK once again. After that, communication with server will happen and either you see “ACCESS GRANTED” and you can carry on through the door or you will see error message and hear 3 long beeps. Here is table with error messages:

Při přistoupení k dveřím je na LCD zobrazeno INSERT ID:. Uživatel zadá ID a potvrdí stiskem klávesy OK. Pak je textem INSERT PIN vyzván k zadání kódu. Poté proběhne komunikace se serverem a při správných údajích vypíše ACCESS GRANTED a jednou krátce pípne. Při špatných údajích vypíše jinou hlášku a 3x dlouze zapíská. Chybové hlášky jsou vidět v tabulce.

Message	meaning
UNKNOWN ID	You wrote ID which is not found in the authorised personel database
UNKNOWN PIN	You wrote incorrect PIN code
NOT AUTHORIZED	Your credentials are correct, but you are not authorised to access this d
UNKNOWN COMMAND	Unexoected situation happend, try again

In case you want to turn off the device, just hold key QUIT. (Despite you won't be able to go through door')